

## User manual

# Solar Grid-tied Inverter

Product Model: SOFAR 3.3~12KTLX-G3



## Contents

|  |        |
|--|--------|
| Preface.....   | IV     |
| 1. Basic Safety Information.....                       | - 1 -  |
| 1.1. Requirement for Installation and Maintenance..... | - 1 -  |
| 1.2. Symbols and signs.....                            | - 4 -  |
| 2. Product Characteristics.....                        | - 7 -  |
| 2.1. Intended Use.....                                 | - 7 -  |
| 2.2. Function Description.....                         | - 11 - |
| 2.3. Electrical block diagram.....                     | - 12 - |
| 2.4. Efficiency and derating curve.....                | - 12 - |
| 3. Installation.....                                   | - 14 - |
| 3.1. Installation Process.....                         | - 14 - |
| 3.2. Checking Before Installation.....                 | - 14 - |
| 3.3. Tools.....  | - 17 - |
| 3.4. Determining the Installation Position.....        | - 19 - |
| 3.5. Moving of inverter.....                           | - 20 - |
| 3.6. Installation.....                                 | - 21 - |
| 4. Electrical Connection.....                          | - 23 - |
| 4.1. Electrical Connection.....                        | - 24 - |
| 4.2. Grounding Connection (PE).....                    | - 25 - |
| 4.3. AC-Output Wiring.....                             | - 26 - |
| 4.4. Connect PV side of inverter (DC-Input).....       | - 29 - |
| 4.5. Communication Connection.....                     | - 32 - |
| 5. Commissioning of inverter.....                      | - 42 - |
| 5.1. Cable Connection Inspection.....                  | - 42 - |
| 5.2. Start Inverter.....                               | - 42 - |
| 5.3. Shutdown inverter.....                            | - 43 - |
| 5.4. Setting power quality response modes.....         | - 43 - |
| 6. Operation interface.....                            | - 44 - |
| 6.1. Operation and Display Panel.....                  | - 44 - |
| 6.2. Standard Interface.....                           | - 45 - |
| 6.3. Main Interface.....                               | - 47 - |
| 6.4. Updating Inverter Software.....                   | - 55 - |
| 7. Trouble shooting and maintenance.....               | - 58 - |
| 7.1. Troubleshooting.....                              | - 58 - |
| 7.2. Maintenance.....                                  | - 67 - |
| 8. Technical Data.....                                 | - 68 - |
| 9. Quality Assurance.....                              | - 74 - |

## Figures and Tables

|  |        |
|--|--------|
| Figure 2- 1 PV Grid-Tied System.....                             | - 7 -  |
| Figure 2- 2 Overview of grid configurations.....                 | - 8 -  |
| Figure 2- 3 Front, side and back of the machine (3.3~12K).....   | - 9 -  |
| Figure 2- 4 Bottom view.....                                     | - 9 -  |
| Figure 2- 5 Mounting bracket dimensions.....                     | - 9 -  |
| Figure 2- 6 Bottom view of the SOFAR 3.3~12KTLX-G3.....          | - 10 - |
| Figure 2- 7 Product label.....                                   | - 10 - |
| Figure 2- 8 Electrical block diagram.....                        | - 12 - |
| Figure 2- 9 Typical efficiency curve (of the 12KW).....          | - 12 - |
| Figure 2- 10 Rated Power ratio vs Grid Voltage.....              | - 13 - |
| Figure 3- 2 Installation position selection.....                 | - 19 - |
| Figure 3- 3 Wall clearances for single inverter.....             | - 20 - |
| Figure 3- 4 Wall clearances for multiple inverters.....          | - 20 - |
| Figure 3- 5 Remove inverter from package (1).....                | - 21 - |
| Figure 3- 6 Remove inverter from package (2).....                | - 21 - |
| Figure 3- 7 Installation instruction (1).....                    | - 22 - |
| Figure 3- 8 Installation instruction (2).....                    | - 22 - |
| Figure 4- 1 Flowchart for connecting cables to the inverter..... | - 24 - |
| Figure 4- 2 Grounding connection instruction (1).....            | - 25 - |
| Figure 4- 3 Grounding connection instruction (2).....            | - 25 - |
| Figure 4- 4 Inverter external grounding instruction diagram..... | - 26 - |
| Figure 4- 5 Incorrect connection between load and inverter.....  | - 27 - |
| Figure 4- 6 AC side CSA vs power loss.....                       | - 28 - |
| Figure 4- 7 A 3 phase cable.....                                 | - 28 - |
| Figure 4- 8 AC cable connection instruction diagram (1).....     | - 29 - |
| Figure 4- 9 AC cable connection instruction diagram (2).....     | - 29 - |
| Figure 4- 10 DC cable connection (1).....                        | - 30 - |
| Figure 4- 11DC cable connection (2).....                         | - 30 - |
| Figure 4- 12 DC cable connection (3).....                        | - 31 - |
| Figure 4- 13 DC cable connection(4).....                         | - 31 - |

|   |        |
|---|--------|
| Figure 4- 14 Use a multimeter to check the positive and negative electrodes | - 31 - |
| Figure 4- 15 Removal DC connector   | - 32 - |
| Figure 4- 16 Communications port  | - 32 - |
| Figure 4- 17 Inverter – RRCR Connection                                     | - 35 - |
| Figure 4- 18 Inverter – RRCR Connection                                     | - 36 - |
| Figure 4- 19 Picture of the RS485/USB converter and PC terminal             | - 37 - |
| Figure 4- 20 Connecting a single inverter via RS485                         | - 37 - |
| Figure 4- 21 Daisy chain multiple inverters via RS485                       | - 37 - |
| Figure 4- 22 Connecting a single wifi logger to wireless router             | - 38 - |
| Figure 4- 23 Connecting multiple wifi loggers to wireless router            | - 38 - |
| Figure 4- 24 Electrical connections (Meter + CT)                            | - 41 - |
| Figure 6- 1 Remove communication broad cover                                | - 56 - |
|   |        |
| Table 3- 1 Package contents   | - 17 - |
| Table 3-2 Installation tools  | - 18 - |
| Table 4- 1 The decisive voltage class (DVC) of terminals                    | - 24 - |
| Table 4- 2 AC breaker and RCD specifications                                | - 27 - |
| Table 4- 3 Recommend COM cable size   | - 33 - |
| Table 4- 4 Com port description   | - 33 - |
| Table 4- 5 Function description of the DRMs terminal                        | - 34 - |
| Table 4- 6 Function description of the terminal                             | - 35 - |
| Table 4- 7 4 port RRCR power levels   | - 35 - |
| Table 4- 8 Function description of the terminal                             | - 36 - |
| Table 4- 9 1 port RRCR power level  | - 36 - |
| Table 6- 1 List of available grid codes                                     | - 49 - |
| Table 7- 1 Error Code / Event List  | - 66 - |

# Preface

## Notice

Thank you on your purchase of a SofarSolar inverter. This manual contains important safety and operational information that assist you in using this product. Please observe all applicable safety regulations that have been mandated by your local electrical supplier.

## Save these instructions!

This manual should be considered a piece of safety equipment and therefore must accompany the device, even when it is transferred to another user or site.

## Copyright Declaration

The copyright of this manual belongs to Shenzhen SOFARSOLAR Co. Ltd. Any corporation or individual should not plagiarise, partially copy or fully copy it (including software, etc), and no reproduction or distribution of it in any form or by any means. All right reserved.

SOFARSOLAR reserves the right of final interpretation. This manual is subject to change according to user's or customer's feedback. Please check our website at <http://www.sofarsolar.com> for latest version.

The current Version updated at 20210812.

The current Version is V1.01-AU.

## Shenzhen SOFARSOLAR Co., Ltd

Location: 401, Building 4, Antongda Industrial Park, District 68, XingDong Community, XinAn Street, BaoAn District, Shenzhen, China.

Postcode: 518000

Company Website: [www.sofarsolar.com](http://www.sofarsolar.com)

Email: [service@sofarsolar.com](mailto:service@sofarsolar.com)

## Outline

This manual is an integral part of SOFAR 3.3~12KTLX-G3. It describes the assembly, installation, commissioning, maintenance and troubleshooting of the product. Please read it carefully before operating.

## Scope of Validity

This manual contains important instructions for:






|                    |                  |                  |
|--------------------|------------------|------------------|
| SOFAR 3.3KTLX-G3   | SOFAR 4.4KTLX-G3 | SOFAR 5KTLX-G3-A |
| SOFAR 5.5KTLX-G3   | SOFAR 6.6KTLX-G3 | SOFAR 8.8KTLX-G3 |
| SOFAR 8.8KTLX-G3-A | SOFAR10KTLX-G3-A | SOFAR 11KTLX-G3  |
| SOFAR 11KTLX-G3-A  | SOFAR 12KTLX-G3  |                  |

## Target Audience

This manual is for qualified electricians. The tasks described in this manual only can be performed by qualified electricians.

## Symbols Used


The following types of safety instruction and general information appear in this document as described below:

|   |   |
|---|---|
|    | “Danger”indicates a hazardous situation which, if not avoided, will result in death or serious injury.                        |
| Danger  |   |
|    | “Warning”indicates a hazardous situation which, if not avoided, could result in death or serious injury                       |
| Warning   |   |
|  | “Caution”indicates a hazardous situation which, if not avoided, could result in minor or moderate injury                      |
| Caution   |   |
|  | “Attention”indicates there are potential risks, if fail to prevent, may lead to equipment cannot normally or property damage. |
| Attention   |   |
|  | “Note”provides additional information and tips that are valuable for the optimal operation of the product.                    |
| Note  |   |

# 1. Basic Safety Information

## Outline of this Chapter

Please read the instruction carefully. Faulty operation may cause serious injury or death.

|   |  |
|---|--|
|  | <p>If you have any question or problem when you read the following information, please contact Shenzhen SOFARSOLAR CO., Ltd.</p> |
| <p>Note</p>   |  |

### Safety Instruction

Introduce the safety instruction during installation and operation of SOFAR 3.3~12KTLX-G3.

### Symbols Instruction

This section gives an explanation of all the symbols shown on the inverter and on the type label.

## 1.1. Requirement for Installation and Maintenance

Installation of SOFAR 3.3~12KTLX-G3 on-grid inverter must conform with laws, regulations, codes and standards applicable in the jurisdiction.

Before installing and adjusting the produce, please read all of instructions, cautions and warnings in this manual.

Before connecting the product to the electrical utility grid, contact the local utility company for allowance. Also, this connection must be made only by qualified electrician.

If the failure persists, please contact the nearest authorized maintenance centre.

If you don't know which service centre is closest to you, please contact your local distributor. Don't attempt to repair the product by yourself, this may lead serious injury or damage.

## Qualified Person



When inverter is working, it contains lethal voltages and went hot in some area. Improper installation or maloperation could cause serial damage and injury. To reduce the risk of personal injury and to ensure the safe installation and operation of the product, only a qualified electrician is allowed to execute transportation, installation, commissioning and maintenance. Shenzhen SOFARSOLAR Co, Ltd does not take any responsibility for the property destruction and personal injury because of any incorrect use.

## Label and Symbols

SOFAR 3.3~12KTLX-G3 has a labels and warning symbols attach the side of product which contains important information and technical data, these labels must not be removed from the device.

## Installation location requirement

Please install inverter on surfaces with enough load bearing capacity (such as walls, PV racks etc.). Ensure adequate clearance around and in particularly above the unit is left for passive/active ventilation. Ensure the inverter is installed in a wall ventilated environment and have enough air-cooling cycle. Air humidity should less than 90%.



## Transportation Requirement

If you find packing problems that may have caused damage of the inverter, or find any visible damage, please notify the transportation company immediately.




The factory packaging is designed to prevent transportation related damage





i.e. violent shocks, humidity, vibration, however if the unit is visibly damaged, do not install it.

### Electrical Connection


Please comply with all the current electrical regulations about accident prevention in dealing with the current inverter.


|   |  |
|---|--|
| <br><b>Danger</b>    | <p>Before the electrical connection, use opaque material to cover the PV modules or disconnect PV string DC switch. PV arrays will produce dangerous voltage if it is exposure under sun.</p>                              |
| <br><b>Warning</b>   | <p>All operation must accomplish by certified electrical engineer</p> <ul style="list-style-type: none"> <li>● Must be trained;</li> <li>● Completely read the manual operation and understand all information.</li> </ul> |
| <br><b>Attention</b> | <p>Must get permission by local utility company before connecting to grid and the connection must be done by certified electricians.</p>   |

### Operation

|   |   |
|---|---|
| <br><b>Danger</b>      | <p>Touching the utility grid or the terminal conductors can lead to lethal electric shock or fire!</p> <p>Do not touch non-insulated cable ends, DC conductors and any live components of the inverter.</p> <p>Attention to any electrical relevant instruction and document.</p> |
| <br><b>Attention</b> | <p>Enclosure or internal components may get hot during operation. Do not touch hot surface or wear insulated gloves.</p> <p>Keep it away from kids!</p>   |

### Maintenance and repair


|  |  |
|--|--|
| <br><b>Danger</b> | <p>Before any repair work, turn OFF the AC circuit breaker between the inverter and electrical grid first, then turn OFF the DC switch.</p> <p>After turning OFF the AC circuit breaker and DC switch wait for at least 5 minutes before carry any maintenance or repair work.</p> |
|--|--|

|   |   |
|---|---|
|  | <p>Inverter should not work again until removing all faults. If any repair work is required, please contact local authorized service centre.</p> <p>Should not open the inverter cover without authorized permit, SOFARSOLAR does not take any responsibility for that.</p> |
| <b>Attention</b>  |   |





## EMC/Noise Level

Electromagnetic compatibility (EMC) refers to that on electrical equipment functions in a given electromagnetic environment without any trouble or error, and impose no unacceptable effect upon the environment. Therefore, EMC represents the quality characters of an electrical equipment.

- The inherent noise-immune character: immunity to internal electrical noise
- External noise immunity: immunity to electromagnetic noise of external system
- Noise emission level: influence of electromagnetic emission upon environment

|   |  |
|---|--|
|  | <p>Electromagnetic radiation from inverter may be harmful to health!</p> <p>Please do not continue. Stay away from the inverter in no less than 20cm when inverter is operational.</p> |
| <b>Danger</b>   |  |







## 1.2. Symbols and signs




|   |   |
|---|---|
|   | <p>High voltage of inverter may be harmful to health!<br/>Only certified engineer can operate the product;<br/>Juveniles, Disable, should not use this product;<br/>Keep this product out of the reach of children;</p> |
| <b>Danger</b>   |   |
|  | <p>Caution of burn injuries due to hot enclosure!<br/>Only touch the screen and pressing key of the inverter while it is working.</p>   |
| <b>Caution</b>  |   |
|  | <p>PV array should be grounded in accordance to the requirements of the local electrical grid company.</p>  |
| <b>Attention</b>  |   |
|  | <p>Ensure input DC voltage &lt; Max. DC voltage .Overvoltage may cause permanent damage to inverter or other losses,</p>  |
| <b>Attention</b>  |   |

**Warning** which will not be included in warranty!

### Warning signs on the device

SOFAR 3.3~12KTLX-G3 has some safety symbols on the inverter. Please read and fully understand the meaning of the symbols before installation.

| Symbols   | Name   | Explanation  |
|---|--|--|
|    | This is a residual voltage in the inverter!    | After disconnect with the DC side, there is a residual voltage in the inverter, operator should wait for 5 minutes to ensure the capacitor is completely discharged.                                     |
|    | Caution of high voltage and electric shock     | The products operates at high voltages. Prior to performing any work on the product, disconnect the product from voltage sources. All work on the product must be carried out by qualified persons only. |
|    | Caution of hot surface                         | The product can get hot during operation. Avoid contact during operation. Prior to performing any work on the product, allow the product to cool down sufficiently                                       |
|    | The product complies with the CE Certification |  |
|  | Grounding Terminal                             | This symbol indicates the position for the connections of an additional equipment grounding conductor  |
|  | Observe the documentation                      | Read all documentation supplied with the product before install  |

|   |                                 |  |
|---|---------------------------------|--|
|  | Positive pole and negative pole | Positive pole and negative pole of the input voltage (DC)  |
|  | Temperature                     | Indicated the temperature allowance range  |
|  | RCM logo                        | RCM (Regulatory Compliance Mark)<br>The product complies with the requirements of the applicable Australian standards. |

# 2. Product Characteristics

## Outline of this Chapter

### Product Dimensions

Introduce the field of use and the dimensions of the product

### Function Description

Introduce working principle and internal components of the product

### Efficiency Curves

Introduce the efficiency curves of the product

## 2.1. Intended Use

### Field of use

SOFAR 3.3~12KTLX-G3 is a transformer-less on grid PV inverter, that converts the direct current of the PV panels to the grid-compliant, three-phase current and feeds into the utility grid.




Figure 2- 1 PV Grid-Tied System

SOFAR 3.3~12KTLX-G3 may only be operated with PV arrays (photovoltaic module and cabling) for on grid condition. Do not use this product for any other or additional purposes. Any damage or property loss due to any use of the product other than described in this section, SOFARSOLAR will not take the responsibility. DC input of the product must be PV module, other source such

like DC sources, batteries will void the manufacturers warranty.

## Intended grid types

SOFAR 3.3~12KTLX-G3 configurations. For the TT type of electricity grid, the voltage between neutral and earth should be less than 30V. inverters are compatible with TN-S, TN-C, TN-C-S, TT, IT grid.




Figure 2- 2 Overview of grid configurations

## Product Dimensions

The choice of optional parts of inverter should be made by a qualified technician who knows the installation conditions clearly.

### Dimensions Description

SOFAR 3.3KTLX-G3

SOFAR 4.4KTLX-G3

SOFAR 5KTLX-G3-A

SOFAR 5.5KTLX-G3

SOFAR 6.6KTLX-G3

SOFAR 8.8KTLX-G3

SOFAR 8.8KTLX-G3-A

SOFAR10KTLX-G3-A

SOFAR 11KTLX-G3

SOFAR 11KTLX-G3-A

SOFAR 12KTLX-G3

L×W×H=430\*385\*182mm




Figure 2-3 Front, side and back of the machine (3.3~12K)




Figure 2-4 Bottom view

**Note:** 3.3KTLX-G3, 4.4KTLX-G3, 5KTLX-G3-A, 5.5KTLX-G3, 6.6KTLX-G3, 8.8KTLX-G3, 11KTLX-G3 supports 2-channel PV string input; 8.8KTLX-G3-A, 10KTLX-G3-A, 11KTLX-G3-A, 12KTLX-G3 supports 3-channel PV string input.




Figure 2-5 Mounting bracket dimensions

## Function description of inverter box (bottom)




Figure 2-6 Bottom view of the SOFAR 3.3~12KTLX-G3

1. DC Switch
2. DC negative connectors
3. DC positive connectors
4. USB Port (for WIFI or Ethernet communication)
5. Breather valve
6. COM Port (for RS485 communication)
7. AC output

## Label on the equipment




Figure 2-7 Product label

Note: label must NOT be hidden with objects and extraneous parts (rags, boxes, equipment, etc.); they must be cleaned regularly and kept visible at all times.



## 2.2. Function Description

DC power generated by PV arrays is filtered through Input Board then enter Power Board. Input Board also offer functions such as insulation impedance detection and input DC voltage/ current detection. DC power is converted to AC power by Power Board. AC power is filtered through Output Board then AC power is fed into the grid. Output Board also offer functions such as grid voltage/ output current detection, GFCI and output isolation relay. Control Board provides the auxiliary power, controls the operation state of inverter and shows the operation status by Display Board. Display Board displays fault code when inverter is abnormal operation conditions. At the same time, Control Board can trigger the replay to protect the internal components.

### Function Module

#### A. Energy management unit

Remote control to start/down inverter through an external control.

#### B. Feeding reactive power into the grid

The inverter is able to produce reactive power thus to feed it into the grid through the setting of the phase shift factor. Feed-in management can be controlled directly by APP or through a RS485 interface.

#### C. Limited the active power fed into grid

If enable the limited of active power function, inverter can limit the amount of active power fed into the grid to the desired value (expressed as percentage).

#### D. Self-power reduction when grid is over frequency

If grid frequency is higher than the limited value, inverter will reduce the output power to ensure the grid stability.

#### E. Data transmission

Inverter or a group of inverters can be monitored remotely through an advanced communication system based on RS485 interface or via USB port.

#### F. Software update

USB interface for uploading the firmware, remotely uploading by using USB acquisition stick (WIFI or Ethernet) is also available.

## 2.3. Electrical block diagram




Figure 2-8 Electrical block diagram

## 2.4. Efficiency and derating curve




Figure 2-9 Typical efficiency curve (of the 12KW)







Figure 2- 10 Rated Power ratio vs Grid Voltage


# 3. Installation

## Outline of this Chapter

This topic describes how to install this product, please read carefully before install.

|   |  |
|---|--|
| <br><b>Dangers</b>   | Do NOT install the product on flammable material.<br>Do NOT store this product in potentially explosive atmospheres.   |
| <br><b>Caution</b>   | The enclosure and heat sink will get hot during operation, please do not mount the product at a easy to reach location.  |
| <br><b>Attention</b> | Consider the weight of this product when doing transport and moving.<br>Choose an appropriate mounting position and surface.<br>At least two persons for installation. |

## 3.1. Installation Process



## 3.2. Checking Before Installation


### Checking Outer Packing Materials








Before unpacking, please check the condition of the outer package materials if any damaged found, such as holes, cracks, please not unpack the product, contact your distributor immediately. Recommend installing the product within 24 hours after unpacking the package.

## Contents

ing, please check according to following table, to see whether all  
ere included in the packing, please contact your distributor  
f anything missing or damage.

| Pictures | Description | Quantity |
|----------|-------------|----------|
|----------|-------------|----------|



|    |   |   |  |
|----|---|---|--|
| 6  |    | PV+ metal pin   | 8.8KTLX-G3-A 3 PCS<br>10KTLX-G3-A 3 PCS<br>11KTLX-G3-A 3 PCS<br>12KTLX-G3 3 PCS<br>3.3KTLX-G3 2 PCS<br>4.4KTLX-G3 2 PCS<br>5KTLX-G3-A 2 PCS<br>5.5KTLX-G3 2 PCS<br>6.6KTLX-G3 2 PCS<br>8.8KTLX-G3 2 PCS<br>11KTLX-G3 2 PCS |
| 7  |    | PV- metal pin   | 8.8KTLX-G3-A 3 PCS<br>10KTLX-G3-A 3 PCS<br>11KTLX-G3-A 3 PCS<br>12KTLX-G3 3 PCS<br>3.3KTLX-G3 2 PCS<br>4.4KTLX-G3 2 PCS<br>5KTLX-G3-A 2 PCS<br>5.5KTLX-G3 2 PCS<br>6.6KTLX-G3 2 PCS<br>8.8KTLX-G3 2 PCS<br>11KTLX-G3 2 PCS |
| 8  |    | M6*12 Hexagon screws                                    | 3 PCS  |
| 9  |    | AC waterproof cover                                     | 1 PCS  |
| 10 |   | M4*12 cross screw<br>(For locking the waterproof cover) | 4 PCS  |
| 11 |  | Manual  | 1PCS   |
| 12 |  | Warranty Card   | 1PCS   |








|    |   |                                    |                  |
|----|---|------------------------------------|------------------|
| 13 |  | Quality Certificate                | 1PCS             |
| 14 |  | R-type terminal                    | 5PCS             |
| 15 |  | Communication Terminal             | 1PCS             |
| 16 |  | USB logger<br>(WIFI/GPRS/Ethernet) | 1 PCS (Optional) |

Table 3- 1 Package contents

### 3.3. Tools

Prepare tools required for installation and electrical connection as following table:

| No | Tool  | Description                               | Function  |
|----|---|---|---|
| 1  |  | Hammer Drill<br>Recommend drill @<br>80mm | Used to drill holes on the wall   |
| 2  |  | Screwdriver                               | Use to tighten and loosen screws when<br>installing AC power cable<br>Use to remove AC connectors from the<br>product |
| 3  |  | Removal Tool                              | Remove PV Connector   |











|    |   |                   |  |
|----|---|-------------------|--|
| 4  |    | Wire Stripper     | Used to peel cable   |
| 5  |    | M6 hexagon wrench | M6 use to uninstall and install the front top cover and down cover |
| 6  |    | Crimping Tool     | Use to crimp cable on grid side, load side and CT extensive cable  |
| 7  |    | Multimeter        | Check grounding cable, PV positive and negative pole               |
| 8  |    | Marker            | Mark signs   |
| 9  |    | Measuring Tape    | Measure distance   |
| 10 |    | Level             | Ensure the rear panel is properly installed                        |
| 11 |   | ESD gloves        | Installer wear when installing product                             |
| 12 |  | Safety goggles    | Installer wear when installing product                             |
| 13 |  | Mask              | Installer wear when installing product                             |

Table 3-2 Installation tools



### 3.4. Determining the Installation Position

This unit is designed to be wall mounted,. When selecting an appropriate location for the inverter, observe the following:

Installed vertically (to within 15° skew) with the AC plug facing downwards

Away from direct sunlight throughout the whole year

Away from areas where debris can collect on top of the unit and block its ability to cool.




Figure 3-2 Installation position selection




Figure 3-3 Wall clearances for single inverter




Figure 3-4 Wall clearances for multiple inverters

### 3.5. Transporting the inverter

Unload the inverter from package, horizontally move to the install position. When opening the package, carefully lift the inverter with hands from the back of heat sink part. At least two operators to lift the inverter up.




Figure 3-5 Remove inverter from package (1)




Figure 3-6 Remove inverter from package (2)



#### Attention

Inverter is heavy, attention to keep the balance when lift the inverter. Dropped while being transported may cause injuries.

Do not put the inverter with wiring terminals contacting the floor because the power ports and signal ports are not designed to support the weight of the inverter

When placing the inverter on the floor, put it above foam or paper to avoid the damage of the casing of the inverter.

## 3.6. Installation

**Step 1:** Place the rear panel on the mounting wall, determine the mounting height of the bracket and mark the mounting poles accordingly. Drilling holes by using Hammer Drill, keep the hammer drill perpendicular to the wall and make sure the position of the holes should be suitable for the expansion bolts.

**Step 2:** Align the rear panel with the hole position, and drive the M6 expansion

bolt in.

**Step 3:** Fix the rear panels on the wall by tightening the M6\*80 Hexagon screws




Figure 3-7 Installation instruction (1)

**Step 4:** Lift the inverter and hang it on the rear panel, and fixing both sides of inverter with the supplied M6 screw.




Figure 3-8 Installation instruction (2)




# 4. Electrical Connection

## Outline of this Chapter

This section introduces the electrical connection for the product. Please read the information carefully, it will be helpful to understand the grounding, DC input, AC output and communication connections and requirements.

### Caution:

Before performing any electrical connections, ensure the DC switch is OFF and AC circuit breaker is OFF. Allow up to 5 minutes for the capacitor to be discharged.

|   |   |
|---|---|
|  | Installation and maintenance should be done by certified electrical engineer  |
| Attention   |   |
|  | Before the electrical connection, use opaque material to cover the PV modules or disconnect PV string DC switch. PV arrays will produce dangerous voltage if it is exposure under sun |
| Danger  |   |
|  | For this product, the open circuit voltage of PV strings should not greater 1100V   |
| Note  |   |

The connected panel must meet the standard IEC61730A.

| String<br>Model  | Isc PV(maximum) | Maximum output current (A) |
|------------------|-----------------|----------------------------|
| SOFAR 3.3KTLX-G3 | 22.5A/22.5A     | 5A                         |
| SOFAR4.4KTLX-G3  | 22.5A/22.5A     | 6.7A                       |
| SOFAR 5KTLX-G3-A | 22.5A/22.5A     | 7.6A                       |
| SOFAR5.5KTLX-G3  | 22.5A/22.5A     | 8.3A                       |
| SOFAR 6.6KTLX-G3 | 22.5A/22.5A     | 10A                        |
| SOFAR 8.8KTLX-G3 | 22.5A/22.5A     | 13.3A                      |

|                    |             |       |
|--------------------|-------------|-------|
| SOFAR 8.8KTLX-G3-A | 22.5A/45A   | 13.3A |
| SOFAR 10KTLX-G3-A  | 22.5A/45A   | 15.2A |
| SOFAR 11KTLX-G3    | 22.5A/22.5A | 16.7A |
| SOFAR 11KTLX-G3-A  | 22.5A/45A   | 16.7A |
| SOFAR 12KTLX-G3    | 22.5A/45A   | 20A   |

Note: In the above table, the first value of  $I_{sc}$  PV is for MPPT 1, the second value of  $I_{sc}$  PV is for MPPT 2.

**NOTE:** The DVC is the voltage of a circuit which occurs continuously between any two live part in the worst-case rated operating condition when used as intended.

| Interface                    | DVC  |
|------------------------------|------|
| PV input interface           | DVCC |
| AC output interface          | DVCC |
| USB interface                | DVCA |
| COM interface                | DVCA |
| WiFi/GPRS/Ethernet interface | DVCA |

Table 4- 1 The decisive voltage class (DVC) of terminals

DC switch parameters

|                                 |         |
|---------------------------------|---------|
| Max insulation voltage          | 1500V   |
| Rated impulse withstand voltage | 8KV     |
| Rated operational current       | 30A     |
| $I_{cw}$                        | 700A 1S |
| $I_{cm}$                        | 200A    |
| $I_{the}$                       | 50A     |

## 4.1. Electrical Connection





Figure 4- 1 Flowchart for connecting cables to the inverter

## 4.2. Grounding Connection (PE)

Connect the inverter to the grounding electrode using ground cable

|   |   |
|---|---|
|  | <p>SOFAR 3.3~12KTLX-G3 is a transformerless inverter which requires the positive pole and negative pole of the PV array to be floating with respect to PE. Otherwise, it will cause inverter failure. In the PV system, all non-current-carrying metal parts (such as mounting frame, combiner box enclosure, etc.) should be connected to earth.</p> |
| <p>Note</p>   |   |

**We recommend the earthing cable to be 2.5mm<sup>2</sup> or greater and to be coloured yellow-green.**

### Procedure:

**Step 1:** Remove the insulation layer with an appropriate length using a wire stripper shown as figure 4-2)




Figure 4- 2 Grounding connection instruction (1)

**Note:** the length of L2 should 2~3mm higher than L1

**Step 2:** Insert the exposed core wires into the OT terminal and crimp them by using a crimping tool, as shown as figure 5.3. Recommend using OT terminal: OT-M6, Cable:  $\geq 6\text{mm}^2$




Figure 4- 3 Grounding connection instruction (2)

**Note 1:** L3 is the length between the insulation layer of the ground cable and crimped part. L4 is the distance between the crimped part and core wires protruding from the crimped part.

**Note 2:** The cavity formed after crimping the conductor crimp strip shall wrap the core wires completely. The core wires shall contact the terminal closely.

**Step 3:** Tighten the OT terminal by using M6 screw. Recommend torque is 5N.m





Figure 4-4 Inverter external grounding instruction diagram

### 4.3. AC-Output Wiring

SOFAR 3.3~12KTLX-G3 connect to utility grid by using AC power cable. The AC connection must meet the requirement of local grid operator

|  |  |
|--|--|
| <br><b>Caution</b> | Ban multiple Inverters use one circuit breaker<br>Ban connect loads between inverter and circuit breaker |
|--|--|

Must use five core outdoor cable, the recommend AC cable and Residual Current Device (RCD) as below table:

| Model            | Cross section area of Cu cable (mm <sup>2</sup> ) | Muti-core outdoor cable (mm) | AC Circuit Breaker specification            |
|------------------|---|------------------------------|---|
| SOFAR 3.3KTLX-G3 | 2~3, recommend 2.5                                | 18~25                        | 16A/230V/3P current leakage protection 0.1A |
| SOFAR 4.4KTLX-G3 | 2~3, recommend 2.5                                | 18~25                        | 16A/230V/3P current leakage protection 0.1A |
| SOFAR 5KTLX-G3-A | 3~4, recommend 3                                  | 18~25                        | 16A/230V/3P current leakage protection 0.1A |



|                    |                  |       |   |
|--------------------|------------------|-------|---|
| SOFAR 5.5KTLX-G3   | 3~4, recommend 3 | 18~25 | 16A/230V/3P current leakage protection 0.1A |
| SOFAR 6.6KTLX-G3   | 3~4, recommend 4 | 18~25 | 20A/230V/3P current leakage protection 0.1A |
| SOFAR 8.8KTLX-G3-A | 4~6, recommend 5 | 18~25 | 25A/230V/3P current leakage protection 0.1A |
| SOFAR 8.8KTLX-G3   | 4~6, recommend 5 | 18~25 | 25A/230V/3P current leakage protection 0.1A |
| SOFAR 10KTLX-G3-A  | 4~6, recommend 5 | 18~25 | 25A/230V/3P current leakage protection 0.1A |
| SOFAR 11KTLX-G3-A  | 5~7, recommend 6 | 18~25 | 32A/230V/3P current leakage protection 0.1A |
| SOFAR 11KTLX-G3    | 5~7, recommend 6 | 18~25 | 32A/230V/3P current leakage protection 0.1A |
| SOFAR 12KTLX-G3    | 5~7, recommend 6 | 18~25 | 32A/230V/3P current leakage protection 0.1A |

Table 4- 2 AC breaker and RCD specifications




Figure 4- 5 Incorrect connection between load and inverter

The resistance at connection point must less than  $2\Omega$ . In case to have a properly anti-islanding function, please choose the high-quality PV cable and ensure the power loss is less than 1%. Meanwhile, the inverter AC side to grid connection point must less than 100m. the relation between cable length, cross section area and power loss as below:




Figure 4-6 AC side CSA vs power loss

The AC output terminal of this product is equipped with high current 5-core terminal block and customised AC output waterproof cover, which can meet the IP65 level requirements for installation.





Figure 4-7 A 3 phase cable

Wiring Procedure as following:

**Step 1:** Select the appropriate cable diameter according to table 4-1, process the cable according to the following picture size requirements, and then pass-through PG waterproof joint;



R type terminal,

Insulating sleeve,

RNBL5-4 (10-12awg).

terminal shall not be exposed.





Figure 4- 8 AC cable connection instruction diagram (1)

**Step 2:** After assembling the PG waterproof connector, connect the cable to the AC terminal block L1, L2, L3, N, PE contacts, and fasten them (1~1.6 N · m). Tighten the lock nut of PG terminal clockwise (5~5.5 N · m).




Figure 4- 9 AC cable connection instruction diagram (2)

## 4.4. Connect PV side of inverter (DC-Input)

DC Switch is a model of the following specifications or equivalent, subject to CEC certification number.

| Inverter model  | Model of DC switch  |
|---|---|
| SOFAR 3.3KTLX-G3<br>SOFAR 4.4KTLX-G3<br>SOFAR 5KTLX-G3-A<br>SOFAR 5.5KTLX-G3<br>SOFAR 6.6KTLX-G3<br>SOFAR 8.8KTLX-G3<br>SOFAR 11KTLX-G3 | XBHP+3319-ADA/6(TUV AZ 69025024 meets<br>AS60947.3:2018<br>The AS/NZS IEC60947 standards) |
| SOFAR 8.8KTLX-G3-A<br>SOFAR 10KTLX-G3-A<br>SOFAR 11KTLX-G3-A<br>SOFAR 12KTLX-G3   | XBHP+3419-AAX/6(TUV AZ 69025024 meets<br>AS60947.3:2018<br>The AS/NZS IEC60947 standards) |

Table 4-2 Recommend DC input cable size (maximum tolerance voltage  $\geq 1100V$  PV cable)

| Copper cable cross section area (mm <sup>2</sup> ) | Cable OD (mm) |
|--|---------------|
| 4~6.0  | 6.0~9.0       |

Step 1: Find the metal contact pins in the accessories bag, connect the cable according below diagram (1.Positive cable, 2. negative cable);




Figure 4-10 DC cable connection (1)

Step 2: Crimp the PV metal contact pin to the striped cable using a proper crimping pliers;




Figure 4-11 DC cable connection (2)

Step 3: Insert wire into the connector cap nut and assemble into the back of male or female plug, When you heard a “click”, the pin tact assembly is seated correctly. (3. Positive Connector, 4. negative connector);




Figure 4- 12 DC cable connection (3)

Step 4: Measure PV voltage of DC input with multimeter, verify DC input cable polar and connect DC connector with inverter until hearing a slight sound indicated connection succeed.




Figure 4- 13 DC cable connection(4)




Figure 4- 14 Use a multimeter to check the positive and negative electrodes

**Note: Please use a multimeter to make sure the PV array positive pole and negative pole!**

If need to remove the PV connector from inverter side, please use the Removal Tool as below diagram, move the connector gently.



NOTE

Before, moving the positive and negative connector, please make sure “DC Switch” is on OFF position.




Figure 4-15 Removal DC connector

## 4.5. Communication Connection



Note

When layout the wiring diagram, please separate the communication wiring and power wiring in case the signal be affected.

3.3~12KTLX-G3 inverter has one USB Port and one COM Port, as shown in the following figure.




Figure 4-16 Communications port


### 4.5.1. USB Port

Port Description:

|          |                       |                               |
|----------|-----------------------|-------------------------------|
| USB port | USB flash disk access | Use for updating the software |
|----------|-----------------------|-------------------------------|

|  |  |  |
|--|--|--|
|  | USB acquisition stick<br>(WIFI or Ethernet) access | Use for remote data acquisition and<br>upgrading of inverter |
|--|--|--|

Procedure:



For details, please refer to the user manual of USB acquisition stick.

## 4.5.2. COM—Multi function communication port

| Name                           | Type   | Outer diameter<br>(mm) | Area<br>(mm <sup>2</sup> ) |
|--------------------------------|--|------------------------|----------------------------|
| RS485<br>Communication<br>Wire | Outdoor shielded twisted<br>pair meets local standards | 2 or 3core: 4~8        | 0.25~1                     |


Table 4- 3 Recommend COM cable size

Port Description:

| PIN   | Define                | Function                     | Note   |
|-------|-----------------------|------------------------------|--|
| 1     | RS485A                | RS485 signal+                | Wire connection monitoring or multiple inverter monitoring |
| 2     | RS485A                | RS485 signal+                |  |
| 3     | RS485B                | RS485 signal-                |  |
| 4     | RS485B                | RS485 signal-                |  |
| 5     | Electric meter RS485A | Electric meter RS485 signal+ | Wire connection Electric meter                             |
| 6     | Electric meter RS485B | Electric meter RS485 signal- |  |
| 7     | GND.S                 | Communication ground         | As RS485 signal ground or DRMS port ground                 |
| 8     | DRM0                  | Remote shut down             | DRMS port  |
| 9     | DRM1/5                | DRMS port logical IO         |  |
| 10    | DRM2/6                |                              |  |
| 11    | DRM3/7                |                              |  |
| 12    | DRM4/8                |                              |  |
| 13-16 | Blank PIN             | N/A                          | N/A  |

Table 4- 4 Com port description

Procedure:



### 4.5.3. Communications Port Description

#### Logic interface

(a) Logic interface for AS/NZS 4777.2:2020, also known as inverter demand response modes (DRMs).

The inverter will detect and initiate a response to all supported demand response commands within 2 s. The inverter will continue to respond while the mode remains asserted.

| Pin NO. | Function |
|---------|----------|
| 9       | DRM1/5   |
| 10      | DRM2/6   |
| 11      | DRM3/7   |
| 12      | DRM4/8   |
| 7       | GND      |
| 8       | DRM0     |

Table 4- 5 Function description of the DRMs terminal

NOTE: Supported DRM command: DRM0, DRM5, DRM6, DRM7, DRM8.

(b) Logic interface for VDE-AR-N 4105:2018-11, is in order to control and/or



limit the inverter's output power.

The inverter can be connected to a RRCR (Radio Ripple Control Receiver) in order to dynamically limit the output power of all the inverters in the installation.




Figure 4- 17 Inverter – RRCR Connection

| Pin NO. | Pin name | Description           | Connected to (RRCR) |
|---------|----------|-----------------------|---------------------|
| 9       | L1       | Relay contact 1 input | K1 - Relay 1 output |
| 10      | L2       | Relay contact 2 input | K2 - Relay 2 output |
| 11      | L3       | Relay contact 3 input | K3 - Relay 3 output |
| 12      | L4       | Relay contact 4 input | K4 - Relay 4 output |
| 7       | G        | GND                   | Relays common node  |

Table 4- 6 Function description of the terminal

Relay status: close is 1, open is 0

| L1 | L2 | L3 | L4 | Active Power | Cos(φ) |
|----|----|----|----|--------------|--------|
| 1  | 0  | 0  | 0  | 0%           | 1      |
| 0  | 1  | 0  | 0  | 30%          | 1      |
| 0  | 0  | 1  | 0  | 60%          | 1      |
| 0  | 0  | 0  | 1  | 100%         | 1      |

Table 4- 7 4 port RRCR power levels

(c) Logic interface for EN50549-1:2019, is in order to cease active power output within five seconds following an instruction being received at the input interface.




Figure 4- 18 Inverter – RRCR Connection

| Pin NO. | Pin name | Description           | Connected to (RRCR) |
|---------|----------|-----------------------|---------------------|
| 9       | L1       | Relay contact 1 input | K1 - Relay 1 output |
| 7       | G        | GND                   | K1 - Relay 1 output |

Table 4- 8 Function description of the terminal

Relay status: close is 1, open is 0

| L1 | Active Power | Power drop rate | Cos( $\varphi$ ) |
|----|--------------|-----------------|------------------|
| 1  | 0%           | <5 seconds      | 1                |
| 0  | 100%         | /               | 1                |

Table 4- 9 1 port RRCR power level

**Step4** Insert the terminal as per the printed label, and then tighten the screws to fix the waterproof cover, rotate the cable gland clockwise to fasten it securely.

This topic describes the functions of the RS485 and WIFI.

## RS485

By RS485 interface, transfer the inverter power output information, alarm information, operation state to the PC terminal or local data acquisition device, then uploaded to the server.




Figure 4-19 Picture of the RS485/USB converter and PC terminal

If only one SOFAR 3.3~12KTLX-G3 is used, use a communication cable, refer to **section 4.5.2** for COM pin definition, and choose either of the two RS485 ports.




Figure 4-20 Connecting a single inverter via RS485

If multiple SOFAR 3.3~12KTLX-G3 are used, connect all SOFAR 3.3~12KTLX-G3 in daisy chain mode over the RS485 communication cable. Set different Modbus address (starting from 1 to 31) for each inverter in the chain.




Figure 4-21 Daisy chain multiple inverters via RS485

Register remote monitoring of SOFAR 3.3~12KTLX-G3 at its relevant website or APP according to monitoring device SN.

## WIFI / Ethernet

By the USB acquisition stick (WIFI / Ethernet), transfer the inverter power output information, alarm information, operation state to the PC terminal or local data acquisition device, then uploaded to the server. Register remote monitoring of SOFAR 3.3~12KTLX-G3 at its relevant website or APP according to monitoring device SN.




Figure 4- 22 Connecting a single wifi logger to wireless router




Figure 4- 23 Connecting multiple wifi loggers to wireless router



- The length of the RS485 communication cable should be less than 1000 m.
- The length of the WIFI communication cable should be less than 100 m.
- If multiple SOFAR 3.3~12KTLX-G3 are connected to the

**Note**

monitoring device over an RS485/USB converter, a maximum of 31 inverters can be connected in a daisy chain.

The operation information (generated energy, alert, operation status) of the inverter can be transferred to PC or uploaded to the server via WiFi/GPRS. Users can choose to use web or APP for monitoring according to their needs. They need to register an account and add the device with the WiFi/GPRS logger serial number. The SN number of the WiFi/GPRS is printed on the box and the WiFi/GPRS.

Web: <https://home.solarmanpv.com>

(Recommended browser: Chrome, Firefox, and Edge).

APP: Android: Go to Android Market and search “SolarMAN smart”.

IOS: Go to App Store and search “SolarMAN smart”.

SolarMAN-3.0- Web User Manual,

Please visit the <https://doc.solarmanpv.com/web/#/7>

SolarMAN-App User Manual,

Please visit the <https://doc.solarmanpv.com/web/#/14>

## Meter

Generation and Export Limit Control functions for the inverter are available but require the use of an external measurement device to obtain grid information.

Note: Meter is supplied separately to the inverter. Please contact your distributor to order a meter.

Connect the wires according to the wiring method as shown in Figure 4-24, and then enable Anti-Reflux Power function and set the Reflux Power limit on the menu interface of the machine. Hard Anti-Reflux also needs to be enabled to take effect. Refer to <6.3 Main interface→A Enter Setting> in this manual for specific operation methods.

Note:

Anti-Reflux Function = Export Limit function

Reflux Power = Export Power

Hard Anti-Reflux control = Hard Export limit control

Anti-Reflux Control = Soft Export limit control

When Anti-Reflux function is enabled, the reflux power of point of common coupling (PCC) will be limited to the set Reflux Power limit.

Both Hard Anti-Reflux Control and Anti-Reflux Control can be used together. However, when Hard Anti-Reflux control is enabled, Anti-Reflux power limit cannot exceed the Hard Anti-Reflux power limit. The limit value is reported to overload protection.

When communication signal with the electricity meter is lost, the output power of the inverter is limited to the value of soft export limit and does not enter the state of fault protection. When Hard anti reflux control is enabled, a loss of communication with the meter will cause the inverter to enter into a fault protection state.





Figure 4- 24 Electrical connections (Meter + CT)

# 5. Commissioning of inverter

## Outline this Chapter

Introduce SOFAR 3.3~12KTLX-G3 safety inspection and start processing

### 5.1. Cable Connection Inspection

|   |   |
|---|---|
| <br><b>Attention</b> | For first time operation, check the AC voltage and DC voltage are within the acceptable range |
|---|---|

AC grid connection

Use multimeter to confirm that three lines and PE line are connect correctly. DC pv connection

Use multimeter to confirm that positive pole and negative pole of PV strings, and the Voc of each string is lower than the inverter max DC input.

### 5.2. Start Inverter

**Step 1:** Turn ON the DC switch.

**Step 2:** Turn ON the AC circuit breaker.

When the DC power generated by the solar array is enough, the SOFAR 3.3~12KTLX-G3 inverter will start automatically. Screen showing “normal” indicates correct operation.

**NOTE 1:** Choose the correct country code. (refer to section 6.3 of this manual)

**NOTE 2:** Different distribution network operators in different countries have different requirements regarding grid connections of PV grid connected inverters.

Therefore, it's very important to make sure that you have selected the correct country code according to requirements of local authority. Please consult qualified electrical engineer or personnel from electrical safety authorities about this.

Shenzhen SOFARSOLAR Co., Ltd. is not responsible for any consequences



arising out of incorrect country code selection.

If the inverter indicates any fault, please refer to Section 7.1 of this manual ——— trouble shooting for help.

### **5.3. Shutdown inverter**

Step 1: Turn OFF the AC circuit breaker.

Step 2: Turn OFF the DC switch.

### **5.4. Setting power quality response modes**

Once the power quality and grid settings have been selected at commissioning, these settings will be locked, and customers cannot modify by themselves. These settings require professional and technical personnel to conduct them by issuing and transmitting instructions on the remote monitoring platform, on the premise that the logger is installed (WiFi/GPRS/Ethernet). And the account must be authorised by SOFARSOLAR.

Power quality settings can be set/view/changed by logging onto solarmanpv.com.

Access to solarmanpv.com is restricted to authorised personnel only (refer to Section 4.5.3 for instructions on accessing solarmanpv.com).

An account must be created to use solarmanpv.com.

Technical personnel can send control instructions on the monitoring page to modify the mode and parameters of the machine, and the corresponding instructions need to be provided by internal professionals.

Once set chosen country grid code has been selected, the current inverter settings, including firmware version can be viewed under the “System Info” menu. Please refer to section 6.3 Main Interface.


# 6. Operation interface

## Outline of this chapter

This section introduces the display, operation, buttons and LED indicator lights of SOFAR 3.3~12KTLX-G3 Inverter.

## 6.1. Operation and Display Panel

### Buttons and Indicator lights



### Button:

- “^” Short press UP button = go up
- “^” Long press UP button = exit menu or current interface
- “v” Short press DOWN button = go down
- “v” Long press DOWN button = enter menu or current interface

### Indicator Lights:

- “GFI” Red light ON = GFCI faulty
- “Normal” Green light flashing = counting down or checking
- “Normal” Green light ON = Normal
- “Alarm” Red light ON= recoverable or unrecoverable faulty

## 6.2. Standard Interface

LCD interface indicated inverter status, alarm information, communication connection, PV input current and voltage, grid voltage, current and frequency, today generation, total generation.

Inverter working status, PV 1 input voltage and current

Normal  
PV1:680V- 6.7A

Inverter working status, PV 2 input voltage and current

Normal  
PV2:683V- 6.8A

Inverter working status, PV generated power

Normal  
Power:9.07kW

Inverter working status, today generated electricity

Normal  
Today:25.594kWh

Inverter working status, total generated electricity

Normal  
Total:25.4kWh

Inverter working status, grid voltage and current

Normal  
GridR:225V-13.5A


Normal  
GridS:228V-13.4A

Normal  
GridT:224V-13.4A

Inverter working status, grid voltage and frequency

Normal  
Grid:226V-50.0Hz

Inverter working status, USB status

Normal  
Power:9.07kW 

Inverter faulty alarm


GridUVP  
Power:0.00kW

When control board successfully connected with communication board, the LCD display the current state of the inverter, display as shown in the figure below.

Wait 3 s  
Power:0.00kW

Check  
Power:0.00kW

Normal  
Today:25.594kWh



Inverter states includes: wait, check, normal and fault


**Wait:** Inverter is waiting to Check State when reconnect the system. In this state, grid voltage value is between the max and min limits and so on; If not, Inverter will go to Fault State or Permanent State.

**Check:** Inverter is checking isolation resistor, relays, and other safety requirements. It also does self-test to ensure inverter software and hardware are well functional. Inverter will go to Fault State or Permanent State if any error or fault occurs.

**Normal:** Inverter enter to Normal State, it is feeding power to the grid; inverter will go to Fault State or Permanent state if any error or fault occurs.

**Fault:** Fault State: Inverter has encountered recoverable error. It should recover if the errors disappear. If Fault State continues; please check the inverter according error code.

When the control board and communication board connection fail, the LCD display interface as shown in the figure below.



## 6.3. Main Interface

Long press the down button under standard interface to enter into main interface, Main interface including below information:

|        |                             |
|--------|-----------------------------|
| Normal | -----Long press DOWN button |
|        | 1.Enter Setting             |
|        | 2.Event List                |
|        | 3.SystemInfo                |
|        | 4.Display Time              |
|        | 5.Software Update           |

(A)Enter setting Interface as below:

|                 |                             |                    |
|-----------------|-----------------------------|--------------------|
| 1.Enter Setting | -----Long press DOWN button |                    |
|                 | 1.Set Time                  | 8.Set Input mode   |
|                 | 2.Clear Energy              | 9.Set Language     |
|                 | 3.Clear Events              | 10.Set Reflux P    |
|                 | 4.Country Code              | 11.Logic Interface |
|                 | 5.On-Off Control            | 12.IV Curve Scan   |
|                 | 6.Set Energy                | 13.Autotest Fast   |
|                 | 7.Set Address               | 14.Autotest STD    |

Long press the button to Enter the main interface of "1. Enter Setting" and long press to enter the setting menu. You can select the content you want to set by short pressing the button.

Note1: Some settings need to enter the password (the default password is 0001), when entering the password, short press to change the number, long press to confirm the current number, and long press after entering the correct password. If "password error, try again" appears, you will need to re-enter the correct password.

### 1. Set Time

Set the system time for the inverter.

### 2. Clear Energy

Clean the inverter of the total power generation.

### 3. Clear Events

Clean up the historical events recorded in the inverter.

### 4. Country Code

This menu is where you can select the country grid parameters, alternatively you can use the mobile APP. To import a country profile you will require the use of a USB drive. Once you insert a USB drive with a valid file you can then select and import it in the "Set SafetyPara" menu.

To use the Bluetooth APP to select the correct country code, the account must be linked and authorised as an installer. Once the country is set, it is read-only and can only be viewed and not modified by the end user.

Please contact and discuss with SOFARSOLAR technical support if you require a non standard parameter set.

| Code |      | Country                 | Code |      | Country         |
|------|------|-------------------------|------|------|-----------------|
| 000  | 000* | Germany VDE4105         | 024  | 000  | Cyprus          |
|      | 001  | Germany BDEW            | 025  | 000  | India           |
|      | 002* | Germany VDE0126         | 026  | 000  | Philippines     |
| 001  | 000  | Italia CEI-021 Internal | 027  | 000  | New Zealand     |
|      | 001* | Italia CEI-016 Italia   | 028  | 000  | Brazil          |
|      | 002* | Italia CEI-021 External |      | 001  | Brazil LV       |
|      | 003  | Italia CEI0-21 In Areti |      | 002  | Brazil 230      |
| 002  | 000  | Australia A             |      | 003  | Brazil 254      |
|      | 008  | Australia-B             | 029  | 000* | Slovakia VSD    |
|      | 009  | Australia-C             |      | 001* | Slovakia SSE    |
| 003  | 000  | Spain RD1699            |      | 002* | Slovakia ZSD    |
| 004  | 000* | Turkey                  | 033  | 000* | Ukraine         |
| 005  | 000  | Denmark                 | 034  | 000  | Norway          |
|      | 001  | Denmark TR322           |      | 001  | Norway-LV       |
| 006  | 000* | Greece Continent        | 035  | 000  | Mexico LV       |
|      | 001* | Greece island           | 038  | 000  | Wide-Range-60Hz |
| 007  | 000* | Netherland              | 039  | 000* | Ireland EN50438 |
| 008  | 000* | Belgium                 | 040  | 000  | Thailand PEA    |
| 009  | 000  | UK G59/G99              |      | 001  | Thailand MEA    |
|      | 001  | UK G83/G98              | 042  | 000  | LV-Range-50Hz   |
| 010  | 000  | China                   | 044  | 000  | South Africa    |
|      | 001  | China Taiwan            | 046  | 000* | Dubai DEWG      |
| 011  | 000* | France                  |      | 001  | Dubai DEWG MV   |
|      | 001  | France FAR Arrete23     | 107  | 000* | Croatia         |
| 012  | 000  | Poland                  | 108  | 000* | Lithuania       |
| 013  | 000  | Austria Tor Erzeuger    |      |      |                 |
| 014  | 000  | Japan                   |      |      |                 |
| 018  | 000  | EU EN50438              |      |      |                 |
|      | 001* | EU EN50549              |      |      |                 |
| 019  | 000  | IEC EN61727             |      |      |                 |
| 020  | 000  | Korea                   |      |      |                 |
| 021  | 000  | Sweden                  |      |      |                 |
| 022  | 000  | Europe General          |      |      |                 |

Table 6- 1 List of available grid codes

### For The Australian Market:

For compliance with AS/NZS 4777.2:2020 please select from

- 002-000 Australia A (Australia Region A)

- 002-008 Australia B (Australia Region B)
- 002-009 Australia C (Australia Region C)

Please contact your local grid operator for which option to select

Note: By selecting 002-000 Australia A, 002-008 Australia B or 002-009 Australia C the power quality response mode and grid protection settings will be reset to their default values for Australia Region A, B, C respectively.

Default grid settings for different regions are shown in the following table:

| Protective function | Protective function limit | Trip delay time | Maximum disconnection time |
|---------------------|---------------------------|-----------------|----------------------------|
| Undervoltage 2(V<<) | 70V                       | 1s              | 2s                         |
| Undervoltage 1(V<)  | 180V                      | 10s             | 11s                        |
| Overvoltage 1(V>)   | 265V                      | 1s              | 2s                         |
| Overvoltage 2(V>)   | 275V                      | -               | 0.2s                       |

|                        | Region                          | Australia A | Australia B | Australia C | New Zealand |
|------------------------|---------------------------------|-------------|-------------|-------------|-------------|
| Under-frequency 1 (F<) | Protective function limit value | 47Hz        | 47Hz        | 45Hz        | 45Hz        |
|                        | Trip delay time                 | 1s          | 1s          | 5s          | 1s          |
|                        | Maximum disconnection time      | 2s          | 2s          | 6s          | 2s          |
| Over-frequency 1 (F>)  | Protective function limit value | 52Hz        | 52Hz        | 55Hz        | 55Hz        |
|                        | Trip delay time                 | -           | -           | -           | -           |
|                        | Maximum disconnection time      | 0.2s        | 0.2s        | 0.2s        | 0.2s        |

Default volt-watt settings for different regions are shown in the following table:

| Region      | Default value                        | $V_{L2}$ | $V_{L1}$ | $V_{W1}$ | $V_{W2}$ |
|-------------|--------------------------------------|----------|----------|----------|----------|
| Australia A | Voltage                              | 207      | 215      | 253      | 260      |
|             | Inverter output (P) % of $S_{rated}$ | 20%      | 100%     | 100%     | 20%      |
| Australia B | Voltage                              | 195      | 215      | 250      | 260      |
|             | Inverter output (P) % of $S_{rated}$ | 0%       | 100%     | 100%     | 20%      |
| Australia C | Voltage                              | 207      | 215      | 253      | 260      |



|  |                                      |     |      |      |     |
|--|--------------------------------------|-----|------|------|-----|
|  | Inverter output (P) % of $S_{rated}$ | 20% | 100% | 100% | 20% |
|--|--------------------------------------|-----|------|------|-----|

Default volt-var settings for different regions are shown in the following table:

| Region      | Default value                                 | $V_{V1}$      | $V_{V2}$ | $V_{V3}$ | $V_{V4}$    |
|-------------|---|---------------|----------|----------|-------------|
| Australia A | Voltage                                       | 207           | 220      | 240      | 258         |
|             | Inverter reactive output (Q) % of $S_{rated}$ | 44% supplying | 0%       | 0%       | 60% sinking |
| Australia B | Voltage                                       | 205           | 220      | 235      | 255         |
|             | Inverter reactive output (Q) % of $S_{rated}$ | 30% supplying | 0%       | 0%       | 40% sinking |
| Australia C | Voltage                                       | 215           | 230      | 240      | 255         |
|             | Inverter reactive output (Q) % of $S_{rated}$ | 44% supplying | 0%       | 0%       | 60% sinking |

## 5. On-Off Control

Inverter on-off local control.

## 6. Set Energy

Set the total power generation. You can modify the total power generation through this option.

## 7. Set address

Set the address (when you need to monitor multiple inverters simultaneously), Default 01.

## 8. Set Input mode

SOFAR 3.3~12KTLX-G3 has 2 MPPT circuit, each MPPT circuit can work interdependently, or divided into parallel mode. User can change the setting according to the configuration

## 9. Set Language

Set the inverter display language.

## 10. Set Reflux P

Enable or disable the export limiting function of the inverter. This function requires to be used with an external CT (CT mode) or an external smart meter (ElecM mode, via RS485), please refer to this manual 4.5.3 CT for details.

|         |                   |            |                 |      |                          |
|---------|-------------------|------------|-----------------|------|--------------------------|
| “Enter” | 1 Enter setting   | “OK”       | 1 Set Time      |      |                          |
|         | 2 Event List      |            | 2 Clean Energy  |      |                          |
| “Up”↑   | 3 System Info     | “Up”↑      | 3 Clean Events  |      |                          |
| “Down”↓ | 4 Display Time    | “Down”↓    | .....           |      |                          |
|         | 5 Software Update |            | 10 Set Reflux P | “OK” | Input password!          |
| “OK”    | ****              | Input 0001 | 0001            | “OK” | Anti Reflux Control      |
|         |                   |            |                 |      | Hard Anti Reflux Control |

|                          |      |         |      |        |                                  |
|--------------------------|------|---------|------|--------|----------------------------------|
| Anti Reflux Control      | “OK” | Enable  | “OK” | *.**KW | Input the allowable export power |
|                          |      | Disable |      |        |                                  |
| Hard Anti Reflux Control | “OK” | Enable  | “OK” | *.**KW | Input the allowable export power |
|                          |      | Disable |      |        |                                  |

Press “Up” or “Down” to change the value of the first digit. Press “OK” to switch to second digit.

Press “Up” or “Down” to change the value of the second digit. After inputting all digit press “OK” to confirm.

## 11. Logic interface

Enable or disable logical interfaces. It is use for below standard Australia (AS4777), Europe General (50549), German (4105)

## 12. IV Curve Scan

Shadow scanning, when the component is blocked or abnormal, causing multiple power peaks, by enabling this function, the peak point of maximum power can be tracked.

## 13. Autotest Fast

|                  |    |                  |                            |
|------------------|----|------------------|----------------------------|
| 13.Autotest Fast | OK | Start Autotest   | Long press the“V” to start |
|                  |    | Testing 59.S1... |                            |
|                  |    | ↓                | Wait                       |
|                  |    | Test 59.S1 OK!   |                            |
|                  |    | ↓                | Wait                       |
|                  |    | Testing 59.S2... |                            |
|                  |    | ↓                | Wait                       |
|                  |    | Test 59.S2 OK!   |                            |
|                  |    | ↓                | Wait                       |

|                                  |                    |
|----------------------------------|--------------------|
| Testing 27.S1...                 |                    |
| ↓                                | Wait               |
| Test 27.S1 OK!                   |                    |
| ↓                                | Wait               |
| Testing 27.S2...                 |                    |
| ↓                                | Wait               |
| Test 27.S2 OK!                   |                    |
| ↓                                | Wait               |
| Testing 81>S1...                 |                    |
| ↓                                | Wait               |
| Test 81>S1 OK!                   |                    |
| ↓                                | Wait               |
| Testing 81>S2...                 |                    |
| ↓                                | Wait               |
| Test 81>S2 OK!                   |                    |
| ↓                                | Wait               |
| Testing 81<S1...                 |                    |
| ↓                                | Wait               |
| Test 81<S1 OK!                   |                    |
| ↓                                | Wait               |
| Testing 81<S2...                 |                    |
| ↓                                | Wait               |
| Test 81<S2 OK!                   |                    |
| ↓                                | Long press the“V”  |
| Auto Test OK!                    |                    |
| ↓                                | Short press the“V” |
| 59.S1 threshold 253V 900ms       |                    |
| ↓                                | Short press the“V” |
| 59.S1: 228V 902ms                |                    |
| ↓                                | Short press the“V” |
| 59.S2 threshold 264.5V<br>200ms  |                    |
| ↓                                | Short press the“V” |
| 59.S2: 229V 204ms                |                    |
| ↓                                | Short press the“V” |
| 27.S1 threshold 195.5V<br>1500ms |                    |
| ↓                                | Short press the“V” |
| 27.S1: 228V 1508ms               |                    |
| ↓                                | Short press the“V” |
| 27.S2 threshold 34.5V 200ms      |                    |
| ↓                                | Short press the“V” |
| 27.S2: 227V 205ms                |                    |
| ↓                                | Short press the“V” |
| 81>.S1 threshold 50.5Hz          |                    |

|                                  |                    |
|----------------------------------|--------------------|
| 100ms                            |                    |
| ↓                                | Short press the“V” |
| 81>.S1 49.9Hz 103ms              |                    |
| ↓                                | Short press the“V” |
| 81>.S2 threshold 51.5Hz<br>100ms |                    |
| ↓                                | Short press the“V” |
| 81>.S2 49.9Hz 107ms              |                    |
| ↓                                | Short press the“V” |
| 81<.S1 threshold 49.5Hz<br>100ms |                    |
| ↓                                | Short press the“V” |
| 81<.S1 50.0Hz 105ms              |                    |
| ↓                                | Short press the“V” |
| 81<.S2 threshold 47.5Hz<br>100ms |                    |
| ↓                                | Short press the“V” |
| 81<.S2 50.1Hz 107ms              |                    |

## 14. Autotest STD

### 14.Autotest STD

Long press the “V”

The test procedure is same as Autotest Fast, but it’s much more time consuming.

### (B) Event List:

Event List is used to display the real-time event records, including the total number of events and each specific ID No. and happening time. User can enter Event List interface through main interface to check details of real-time event records, Event will be listed by the happening time, and recent events will be listed in the front. Please refer to below picture. Long press the button and short press the button to turn the page in standard interface, then enter into “2. Event List” interface.

| 2. Event List     |  |
|-------------------|--|
| 1. Current event  | 2. History event   |
| Fault information | 001 ID04 06150825<br>(Display the event sequence number, event ID number, and event occurrence time) |

### (A) “SystemInfo” Interface as below

### 3.SystemInfo

-----Long press DOWN button

|                         |
|-------------------------|
| <b>1.Inverter Type</b>  |
| <b>2.Serial Number</b>  |
| <b>3.Soft Version</b>   |
| <b>4.Hard Version</b>   |
| <b>5.Country</b>        |
| <b>6.Modbus Address</b> |
| <b>7.Input Mode</b>     |

The user enters the main menu by long pressing the DOWN button, short press and turns the page to select menu contents, then long press the button to enter "3. SystemInfo". Turning the page down can select the system information to view.

### **(B) Display Time**

Long press the button and short press the button to turn the page in the standard user interface to enter into "4. Display Time", then long press the button to display the current system time.

### **(C) Software Update**

User can update software by USB flash disk, SOFARSOLAR will provide the new update software called firmware for user if it is necessary, the user needs to copy the upgrade file to the USB flash disk.

## **6.4. Updating Inverter Software**

SOFAR 3.3~12KTLX-G3 inverter offer software upgrade via USB flash drive to maximize inverter performance and avoid inverter operation error caused by software bugs.

**Step 1:** Turn off AC circuit breaker and DC switch, remove the communication board cover as below figure. If the RS485 line has been connected, please release the waterproof nut first and make sure the communication line is no longer the force. Then remove the waterproof cover.




Figure 6-1 Remove communication broad cover

**Step 2:** Insert USB into computer

**Step 3:** SOFARSOLAR service team will send the software code to user, after user received the file, please decompress the files and the original folder to a USB flash drive.

**Step 4:** Insert USB flash disk into the USB port of inverter

**Step 5:** Then turn on DC switch, screen show “recoverable fault” (as AC circuit breaker still open, inverter cannot detect grid power, so it may show “recoverable fault”)

**Step 6 :** Long press “DOWN” button to enter the menu, then short press “DOWN” button to find "5. Software Update" in the LCD display, long press “DOWN” button to enter input password interface.

**Step 7 :** Input the password, if password is correct, and then begin the update process.

**Step 8 :** System update main DSP, slave DSP and ARM in turns. If main DSP update success, the LCD will display “Update DSP1 Success”, otherwise display "Update DSP1 Fail"; If slave DSP update success, the LCD will display"Update DSP2 Success", otherwise display "UpdateDSP2 Fail".

**Step 9:** After the update is completed, turn off the DC breaker, wait for the LCD screen extinguish, then recover the communication waterproof and then turn on the DC breaker and AC breaker again, the inverter will enter the running state. User can check the current software version in SystemInfo>>3.SoftVersion.

**Note:** If screen shows “Communication fail”, “Update DSP1 fail”, “Update

DSP2 fail” please turn off the DC switch, wait for the LCD screen turn off, then turn on the DC switch again, then Continue to update from step 5.

# 7. Trouble shooting and maintenance

## 7.1. Troubleshooting

This section describes the potential errors for this product. Please read carefully for the following tips when doing the troubleshooting:

- 1) Check the warning message or faulty codes on the inverter information panel
- 2) If not any error code display on the panel, please check the following lists:
  - Is inverter be installed in a clean, dry, ventilated environment?
  - Is the DC switch turn off?
  - Are the cable cross section area and length meet the requirement?
  - Are the input and output connection and wiring in good condition?
  - Are the configuration settings correctly for the particular installation?

This section contains the potential errors, resolution steps, and provide users with troubleshooting methods and tips

### Earth Fault Alarm

This inverter complies with AS/NZS 5033 for earth fault alarm monitoring.

If an Earth Fault Alarm occurs, the fault will be displayed on the LCD screen, the red light will be on, and the fault can be found in the history of the fault. For the machine installed with Wi-Fi/GPRS, the alarm information can be seen on the corresponding monitoring website, and can also be received by the APP on the mobile phone.

The process to check the event list can refers to Manual Chapter 7.3 (B)



| Even List ID | Event List Name | Description                           | Even Reason & Solution   |
|--------------|-----------------|---------------------------------------|--|
| ID01         | GridOVP         | The power grid voltage is too high    | If the alarm occurs occasionally, the possible cause is that the electric grid is abnormal occasionally. inverter automatically returns to normal operating status when the electric grid's back to normal.  |
| ID02         | GridUVP         | The power grid voltage is too low     | If the alarm occurs frequently, check whether the grid voltage/frequency is within the acceptable range. If no, contact technical support. If yes, check the AC circuit breaker and AC wiring of the inverter.   |
| ID03         | GridOFP         | The power grid frequency is too high  | If the grid voltage/frequency is within the acceptable range and AC wiring is correct, while the alarm occurs repeatedly, contact technical support to change the grid over-voltage, under-voltage, over frequency, under-frequency  |
| ID04         | GridUFP         | The power grid frequency is too low   | protection points after obtaining approval from the local electrical grid operator.  |
| ID05         | GFCIFault       | GFCI Fault                            | If the fault occurs occasionally, the possible cause is that the external circuits are abnormal occasionally. inverter automatically returns to normal operating status after the fault is rectified. If the fault occurs frequently and lasts a long time, check whether the insulation resistance between the PV array and earth(ground) is too low, then check the insulation conditions of PV cable. |
| ID06         | OVRT            | OVRT faulty                           | There are internal faults of inverter, turn OFF the "DC switch", wait for 5 minutes, then turn ON the "DC switch". Check whether the fault is rectified. If no, please contact technical support.  |
| ID07         | LVRT            | LVRT faulty                           |  |
| ID08         | IslandFault     | Islanding faulty                      |  |
| ID09         | GridOVInstant1  | Grid instantaneous voltage too high 1 |  |
| ID10         | GridOVInstant2  | Grid instantaneous voltage too high 2 |  |
| ID11         | VGridLineFault  | Grid Line voltage Faulty              |  |
| ID12         | InvOVP          | Inverter overvoltage                  |  |

|      |                           |  |  |
|------|---------------------------|--|--|
| ID17 | HwADFault<br>IGrid        | The grid current sampling error  |  |
| ID18 | HwADFault<br>DCI          | The DCI sampling error   |  |
| ID19 | HwADFault<br>VGrid(DC)    | Grid voltage sampling faulty (DC side)   |  |
| ID20 | HwADFault<br>VGrid(AC)    | Grid voltage sampling faulty (AC side)   |  |
| ID21 | GFCIDevic<br>eFault(DC)   | Current leakage sampling (DC side)   | There are internal faults of inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact technical support.                                |
| ID22 | GFCIDevic<br>eFault(AC)   | Current leakage sampling (AC side)   |  |
| ID23 | HwADFault<br>IdcBranch    | Current Branch sampling faulty   |  |
| ID24 | HwADFault<br>Idc          | DC input current sampling faulty   |  |
| ID29 | ConsistentF<br>ault_GFCI  | The GFCI sampling value between the master DSP and salve DSP is not consistent |  |
| ID30 | ConsistentF<br>ault_Vgrid | The Grid voltage sampling value between the master and salve is not consistent |  |
| ID31 | ConsistentF<br>ault_DCI   | 3 lines' DCI consistency error   | There are internal faults of inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact technical support.                                |
| ID33 | SpiCommF<br>ault(DC)      | SPI Communication Faulty (DC side)   |  |
| ID34 | SpiCommF<br>ault(AC)      | SPI Communication Faulty (AC side)   |  |
| ID35 | SChip_Faul<br>t           | Chip Faulty (DC side)  |  |
| ID36 | MChip_Fau<br>lt           | Chip Faulty (AC side)  |  |
| ID37 | HwAuxPow<br>erFault       | Auxiliary power fault  |  |
| ID41 | RelayFail                 | Relay faulty   | Please check whether the resistance to ground of PV string is too low and whether the insulation of PV cable is damaged. If the use method is not ruled out, please contact the new energy customer service of Capital Airlines. |
| ID42 | IsoFault                  | Low isolation faulty   |  |
| ID43 | PEConnect<br>Fault        | Ground faulty  |  |

|      |                     |  |   |
|------|---------------------|--|---|
| ID44 | PvConfigError       | Input mode incorrect                   | Please check the wiring of PV string, whether each PV input is independent. If the use method is not ruled out, please contact the new energy customer service of Capital Airlines.   |
| ID45 | CT Disconnect       | CT Fault                               | Please check the wiring of input, output and communication according to the user's manual. If the use method is not ruled out, please contact the new energy customer service of Capital Airlines.  |
| ID46 | ReversalConnection  | Input reverse connection error         |   |
| ID47 | Reserved            | Reserved                               |   |
| ID48 | SNTYPEFault         | SN doesn't match Type                  | It is internal fault of inverter.   |
| ID49 | Reserved            | Reserved                               | Ensure the installation position and installation method<br><br>meet the requirements of this user manual. Check whether the ambient temperature of the installation position exceeds the upper limit. If yes, improve ventilation to decrease the temperature. Check whether the inverter has dust and dust, whether there are foreign matters blocking the fan at the air inlet. If so, please improve the ventilation and heat dissipation of the environment. It is recommended that the inverter should be cleaned once every half a year. |
| ID50 | TempFault_HeatSink1 | Heat sink1 over-temperature protection |   |
| ID51 | Reserved            | Reserved                               |   |
| ID52 | Reserved            | Reserved                               |   |
| ID53 | Reserved            | Reserved                               |   |
| ID54 | Reserved            | Reserved                               |   |
| ID55 | Reserved            | Reserved                               |   |
| ID57 | TempFault_Env1      | environment temperature1 protection    |   |
| ID58 | Reserved            | Reserved                               |   |
| ID59 | TempFault_Inv1      | Model 1 over-temperature protection    |   |
| ID60 | Reserved            | Reserved                               |   |
| ID61 | Reserved            | Reserved                               |   |
| ID65 | VbusRmsUnbalance    | Unbalanced RMS value of bus voltage    | There are internal faults of inverter, turn OFF the "DC switch", wait for 5 minutes, then turn ON the   |

|      |                          |  |  |
|------|--------------------------|--|--|
| ID66 | VbusInstant<br>Unbalance | Unbalanced instantaneous<br>value of bus voltage                   |  |
| ID67 | BusUVP                   | Bus undervoltage during<br>grid connection                         | If the configuration of the PV array is correct,<br>could be the sun irradiation is too low. Once sun<br>irradiation back to normal, inverter will work back<br>normal                                     |
| ID68 | BusZVP                   | Bus voltage is low   |  |
| ID69 | PVOVP                    | PV overvoltage   |  |
| ID70 | Reserved                 | Reserved   |  |
| ID71 | LLCBusOV<br>P            | LLCBUS overvoltage   |  |
| ID72 | SwBusRms<br>OVP          | Inverter bus voltage<br>overvoltage software                       | There are internal faults of inverter, turn OFF the<br>“DC switch”, wait for 5 minutes, then turn ON the<br>“DC switch”. Check whether the fault is rectified.<br>If no, please contact technical support. |
| ID73 | SwBusInsta<br>ntOVP      | Inverter bus voltage<br>instantaneous value<br>overvoltagesoftware |  |
| ID81 | Reserved                 | Reserved   |  |
| ID82 | DciOCP                   | Dci overcurrent faulty   | There are internal faults of inverter, turn OFF the<br>“DC switch”, wait for 5 minutes, then turn ON the<br>“DC switch”. Check whether the fault is rectified.<br>If no, please contact technical support. |
| ID83 | SwOCPIInst<br>ant        | Output instantaneous<br>current protection                         |  |
| ID84 | SwBuckBo<br>ostOCP       | BuckBoost software<br>overcurrent                                  |  |
| ID85 | SwAcRmsO<br>CP           | Output RMS current<br>protection                                   |  |
| ID86 | SwPvOCPI<br>nstant       | PV overcurrent software<br>protection                              |  |
| ID87 | IpvUnbalan<br>ce         | PV parallel unbalance  |  |
| ID88 | IacUnbalan<br>ce         | Output current unbalance   |  |
| ID89 | AFCIFault                | Arc Fault  |  |
| ID97 | HwLLCBus<br>OVP          | LLC hardware<br>overvoltage  |  |

|       |                   |                                   |   |
|-------|-------------------|-----------------------------------|---|
| ID98  | HwBusOVP          | Inverter bus hardware overvoltage | <p>There are internal faults of inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact technical support.</p>  |
| ID99  | HwBuckBoostOCP    | BuckBoost hardware overcurrent    |   |
| ID100 | Reserved          | Reserved                          |   |
| ID102 | HwPVOCP           | PV hardware overcurrent           |   |
| ID103 | HwACOCP           | AC output hardware overcurrent    |   |
| ID110 | Overload1         | Overload Protection 1             |   |
| ID111 | Overload2         | Overload Protection 2             |   |
| ID112 | Overload3         | Overload Protection 3             |   |
| ID113 | OverTemp Derating | Overtemperature derating          | <p>Ensure the installation position and installation method meet the requirements of this user manual. Check whether the ambient temperature of the installation position exceeds the upper limit. If yes, improve ventilation to decrease the temperature.</p> <p>Check whether the inverter has dust and dust, whether there are foreign matters blocking the fan at the air inlet. If so, please improve the ventilation and heat dissipation of the environment. It is recommended that the inverter should be cleaned once every half a year.</p>  |
| ID114 | FreqDerating      | Frequency derating                | <p>If it occurs frequently, please check whether the grid voltage and grid frequency are within the allowable range of the inverter; if not, please contact the customer service of SOFARSOLAR; if yes, please check whether the connection between the circuit breaker at the AC side and the output cable is normal; if the grid voltage and grid frequency are within the allowable range of the inverter, and the AC side wiring is confirmed to be correct, the alarm still appears frequently With the approval of the local power operator, please contact the customer service of new energy of Capital Airlines to modify the protection points of over / under voltage and over / under frequency of inverter grid.</p> |
| ID115 | FreqLoading       | Frequency loading                 |   |
| ID116 | VoltDerating      | Voltage derating                  |   |

|       |                                |  |   |
|-------|--------------------------------|--|---|
| ID117 | VoltLoadin<br>g                | Volatge loading                                    |   |
| ID124 | Reserved                       | Reserved   |   |
| ID125 | Reserved                       | Reserved   |   |
| ID129 | unrecoverH<br>wAcOCP           | Output overcurrent<br>hardwarepermanent fault      | There are internal faults of inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact technical support. |
| ID130 | unrecoverB<br>usOVP            | Busovervoltagepermanen<br>t fault                  |   |
| ID131 | unrecoverH<br>wBusOVP          | Busovervoltage hardware<br>permanent fault         |   |
| ID132 | unrecoverIp<br>vUnbalance      | PV unbalance current<br>permanent fault            |   |
| ID133 | Reserved                       | Reserved   |   |
| ID134 | unrecoverA<br>cOCPInstan<br>t  | Output transient<br>overcurrent permanent<br>fault |   |
| ID135 | unrecoverIa<br>cUnbalance      | Output current imbalance<br>permanent fault        |   |
| ID137 | unrecoverP<br>vConfigErr<br>or | Input mode configuration<br>permanent fault        |   |
| ID138 | unrecoverP<br>VOCPInsta<br>nt  | Input overcurrent<br>permanent fault               |   |
| ID139 | unrecoverH<br>wPVOC            | Input hardware<br>overcurrent permanent<br>fault   | There are internal faults of inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact technical support. |
| ID140 | unrecoverR<br>elayFail         | Relay permanent fault                              |   |

|       |                                    |   |  |
|-------|------------------------------------|---|--|
| ID141 | unrecoverV<br>busUnbalan<br>ce     | Bus Unbalanced<br>permanent fault               |  |
| ID142 | LightningPr<br>otectionFaul<br>tDC | DC SPD failure                                  |  |
| ID143 | LightningPr<br>otectionFaul<br>tAC | AC SPD failure                                  |  |
| ID145 | USBFault                           | USB Failure                                     |  |
| ID146 | WiFiFault                          | WIFI failure                                    |  |
| ID147 | BluetoothFa<br>ult                 | Bluetooth failure                               |  |
| ID148 | RTCFault                           | RTCClock failure                                | <p>There are internal faults of inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact technical support.</p> |
| ID149 | CommEEP<br>ROMFault                | Communication BOARD<br>EEPROM error             |  |
| ID150 | CommEEP<br>ROMFault                | Communication BOARD<br>FLASH error              |  |
| ID151 | Reserved                           | Reserved  |  |
| ID152 | SafetyVerF<br>ault                 | Safety Version is Fault                         |  |
| ID153 | SciCommL<br>ose(DC)                | SCI communication (DC<br>side)                  |  |
| ID154 | SciCommL<br>ose(AC)                | SCI communication (AC<br>side)                  |  |
| ID155 | SciCommL<br>ose(Fuse)              | SCI communication (DC<br>current combined side) |  |
| ID156 | SoftVerErro<br>r                   | Inconsistent software<br>version                |  |
| ID157 | Reserved                           | Reserved  |  |

|             |                        |                                |   |
|-------------|------------------------|--------------------------------|---|
| ID158       | Reserved               | Reserved                       |   |
| ID161       | ForceShutdown          | ForceShutdown                  | Remote control enables. If it is not controlled by yourself, please disconnect the DC switch of the inverter, wait for 5 minutes, and then turn on the DC switch. Observe whether the fault has been eliminated after the inverter is restarted. If not, please contact the customer service of SOFARSOLAR. |
| ID162       | RemoteShutdown         | RemoteShutdown                 |   |
| ID163       | Drms0Shutdown          | Drms0 shut down                |   |
| ID165       | RemoteDerating         | RemoteDerating                 | Inverter shows ID83 when remote derating. If no one operate this function, please check the connection (I/O) according to chapter 4.5   |
| ID166       | LogicInterfaceDerating | Logical interface derating     |   |
| ID167       | AlarmAntiReflexing     | Anti Refluxing derating        |   |
| ID169       | FanFault1              | Fan 1 Alarm                    | Check whether the inverter has dust and dust, whether there are foreign matters blocking the fan at the air inlet. If so, please improve the ventilation and heat dissipation of the environment. It is recommended that the inverter should be cleaned once every half a year.                             |
| ID170       | FanFault2              | Fan 2 Alarm                    |   |
| ID171       | FanFault3              | Fan 3 Alarm                    |   |
| ID172       | FanFault4              | Fan 4 Alarm                    |   |
| ID173       | FanFault5              | Fan 5 Alarm                    |   |
| ID174       | FanFault6              | Fan 6 Alarm                    |   |
| ID177       | Reserved               | Reserved                       |   |
| ID178       | Reserved               | Reserved                       |   |
| ID179       | Reserved               | Reserved                       |   |
| ID180       | Reserved               | Reserved                       |   |
| ID181       | Reserved               | Reserved                       |   |
| ID182       | Reserved               | Reserved                       |   |
| ID193-ID224 | StringFuse_Fault0-31   | String fuse open circuit alarm | There are internal faults of inverter, turn OFF the “DC switch”, wait for 5 minutes, then turn ON the “DC switch”. Check whether the fault is rectified. If no, please contact technical support.   |
| ID225-ID240 | Reserved               | Reserved                       | /   |

Table 7- 1 Error Code / Event List



Note: the above table is our general fault ID list, all fault IDs of this inverter can be found in the above table.

## 7.2. Maintenance

Inverters generally do not need any daily or routine maintenance. But ensure heat sink should not be blocked by dust, dirt or any other items. Before cleaning, make sure that the DC SWITCH is turned OFF and the circuit breaker between inverter and electrical grid is turned OFF. Wait at least for 5 minutes before Cleaning.

### ✧ Inverter cleaning

Please clean the inverter with an air blower, a dry & soft cloth or a soft bristle brush. Do NOT clean the inverter with water, corrosive chemicals, detergent, etc.

### ✧ Heat sink cleaning

For the long-term proper operation of inverters, ensure there is enough space around the heat sink for ventilation, check the heat sink for blockage (dust, snow, etc.) and clean them if they exist. Please clean the heat sink with an air blower, a dry & soft cloth or a soft bristle brush. Do NOT clean the heat sink with water, corrosive chemicals, detergent, etc.

# 8. Technical Data

## Outlines of this Chapter

This chapter outline the SOFAR 3.3~12KTLX-G3 model type and technical parameters

| Datasheet  | SOFAR<br>3.3KTLX<br>-G3 | SOFAR<br>4.4KTLX<br>-G3 | SOFAR<br>5KTLX<br>-G3-A | SOFAR<br>5.5KTLX<br>-G3 | SOFAR<br>6.6KTLX<br>-G3 | SOFAR<br>8.8KTLX<br>-G3 | SOFAR<br>11KTLX<br>-G3 |
|--|-------------------------|-------------------------|-------------------------|-------------------------|-------------------------|-------------------------|------------------------|
| Input (DC)                                       |                         |                         |                         |                         |                         |                         |                        |
| Recommended Max. PV<br>input power (Wp)          | 4500                    | 6000                    | 7500                    | 7500                    | 9000                    | 12000                   | 15000                  |
| Max. DC power for<br>single MPPT (W)             | 4500                    | 6000                    | 6000                    | 6000                    | 7500                    | 7500                    | 7500                   |
| Number of MPP trackers                           | 2                       |                         |                         |                         |                         |                         |                        |
| Number for DC inputs                             | 1/1                     | 1/1                     | 1/1                     | 1/1                     | 1/1                     | 1/1                     | 1/1                    |
| Max. input voltage                               | 1100V                   |                         |                         |                         |                         |                         |                        |
| Start-up voltage                                 | 160V                    |                         |                         |                         |                         |                         |                        |
| Rated input voltage                              | 650V                    |                         |                         |                         |                         |                         |                        |
| MPPT operating voltage<br>range                  | 140V-1000V              |                         |                         |                         |                         |                         |                        |
| Full power MPPT<br>voltage range (V)             | 160-850                 | 190V-850                | 240-850                 | 240-850                 | 290-850                 | 380-850                 | 420-850                |
| Max. input MPPT<br>current (A)                   | 15/15                   | 15/15                   | 15/15                   | 15/15                   | 15/15                   | 15/15                   | 15/15                  |
| Max. input short circuit<br>current per MPPT (A) | 22.5/22.5               | 22.5/22.5               | 22.5/22.5               | 22.5/22.5               | 22.5/22.5               | 22.5/22.5               | 22.5/22.5              |
| Maximum inverter<br>backfeed current to array    | 0A                      |                         |                         |                         |                         |                         |                        |
| Output (AC)                                      |                         |                         |                         |                         |                         |                         |                        |
| Rated power(VA)                                  | 3000                    | 4000                    | 5000                    | 5000                    | 6000                    | 8000                    | 10000                  |
| Max. AC power (VA)                               | 3300                    | 4400                    | 5000                    | 5500                    | 6600                    | 8800                    | 11000                  |
| Rated output current (A)                         | 4.3                     | 5.8                     | 7.2                     | 7.2                     | 8.7                     | 11.6                    | 14.5                   |
| Max. output current (A)                          | 5                       | 6.7                     | 7.6                     | 8.3                     | 10                      | 13.3                    | 16.7                   |

|                                       |   |        |        |        |        |        |        |
|---------------------------------------|---|--------|--------|--------|--------|--------|--------|
| Nominal grid voltage                  | 3/N/PE, 230V/400Vac                               |        |        |        |        |        |        |
| Grid voltage range                    | 310Vac-480Vac (According to local standard)       |        |        |        |        |        |        |
| Nominal frequency                     | 50 Hz   |        |        |        |        |        |        |
| Grid frequency range                  | 45Hz-55Hz/54Hz-66Hz (According to local standard) |        |        |        |        |        |        |
| Active power adjustable range         | 0~100%  |        |        |        |        |        |        |
| THDi                                  | <3%   |        |        |        |        |        |        |
| Power factor                          | 1 default ( adjustable+/-0.8)                     |        |        |        |        |        |        |
| Current (inrush)                      | 23.9A /20ms                                       |        |        |        |        |        |        |
| Maximum output fault current          | 66a.c.A ,2μs                                      |        |        |        |        |        |        |
| Maximum output overcurrent protection | 20.0a.c.A   |        |        |        |        |        |        |
| Performance                           |   |        |        |        |        |        |        |
| Max efficiency                        | 98.40%  | 98.40% | 98.40% | 98.40% | 98.40% | 98.50% | 98.50% |
| European weighted efficiency          | 97.50%  | 97.50% | 97.50% | 97.50% | 97.50% | 98.00% | 98.00% |
| Self-consumption at night             | <1W   |        |        |        |        |        |        |
| MPPT efficiency                       | >99.9%  |        |        |        |        |        |        |
| Protection                            |   |        |        |        |        |        |        |
| DC reverse polarity prote             | Yes   |        |        |        |        |        |        |
| Anti-islanding protection             | Yes   |        |        |        |        |        |        |
| Leakage current protection            | Yes   |        |        |        |        |        |        |
| Ground fault monitoring               | Yes   |        |        |        |        |        |        |
| PV-array string fault monitoring      | Yes   |        |        |        |        |        |        |
| Anti reverse power function           | Yes   |        |        |        |        |        |        |
| DC switch                             | Yes   |        |        |        |        |        |        |
| AFCI protection                       | Optional  |        |        |        |        |        |        |
| Input/ output SPD                     | PV: type II standard, AC: type II standard        |        |        |        |        |        |        |
| Protective class                      | Class I   |        |        |        |        |        |        |
| Overvoltage category                  | PV: OVC II, AC mains: OVC III                     |        |        |        |        |        |        |
| Detection methods of                  | Reactive Power Disturbance                        |        |        |        |        |        |        |

|                                   |  |       |       |       |       |       |       |
|-----------------------------------|--|-------|-------|-------|-------|-------|-------|
| isolated islands                  |  |       |       |       |       |       |       |
| Communication                     |  |       |       |       |       |       |       |
| Communication                     | RS485/USB/ Bluetooth, Optional: WiFi/GPRS  |       |       |       |       |       |       |
| General Data                      |  |       |       |       |       |       |       |
| Ambient temperature range         | -30℃~+60℃  |       |       |       |       |       |       |
| Topology                          | Transformerless  |       |       |       |       |       |       |
| Degree of protection              | IP65   |       |       |       |       |       |       |
| Allowable relative humidity range | 0~100%   |       |       |       |       |       |       |
| Max. operating altitude           | 2000m  |       |       |       |       |       |       |
| Noise                             | ≤40dB  | ≤40dB | ≤40dB | ≤40dB | ≤40dB | ≤40dB | ≤40dB |
| Weight                            | 17kg   | 17kg  | 17kg  | 17kg  | 17kg  | 17kg  | 18kg  |
| Cooling                           | Natural  |       |       |       |       | Fan   |       |
| Dimension                         | 430*385*182mm  |       |       |       |       |       |       |
| Display                           | LCD&Bluetooth +APP   |       |       |       |       |       |       |
| Standard warranty                 | 10 years   |       |       |       |       |       |       |
| Standard                          |  |       |       |       |       |       |       |
| EMC                               | EN61000-6-1, EN61000-6-2, EN61000-6-3, EN61000-6-4   |       |       |       |       |       |       |
| Safety standard                   | IEC62109-1/2, IEC62116, IEC61727, IEC61683, IEC60068(1,2,14,30)  |       |       |       |       |       |       |
| Grid standard                     | AS/NZS 4777, VDE V 0124-100, V 0126-1-1, VDE-AR-N 4105, CEI 0-21/CEI 0-16, UNE 206 007-1, EN50549, G98/G99, EN50530, NB/T32004 |       |       |       |       |       |       |

| Datasheet   | SOFAR<br>8.8KTLX<br>-G3-A                         | SOFAR<br>10KTLX<br>-G3-A | SOFAR<br>11KTLX<br>-G3-A | SOFAR<br>12KTLX<br>-G3 |
|---|---|--------------------------|--------------------------|------------------------|
| Input (DC)  |   |                          |                          |                        |
| Recommended<br>Max. PV input<br>power (Wp)          | 12000   | 15000                    | 15000                    | 18000                  |
| Max. DC power for<br>single MPPT (W)                | 7500/15000  | 7500/15000               | 7500/15000               | 7500/15000             |
| Number of MPP<br>trackers                           | 2   |                          |                          |                        |
| Number for DC<br>inputs                             | 1/2   | 1/2                      | 1/2                      | 1/2                    |
| Max. input voltage                                  | 1100V   |                          |                          |                        |
| Start-up voltage                                    | 160V  |                          |                          |                        |
| Rated input voltage                                 | 650V  |                          |                          |                        |
| MPPT operating<br>voltage range                     | 140V-1000V  |                          |                          |                        |
| Full power MPPT<br>voltage range (V)                | 380-850   | 420-850                  | 420-850                  | 460-850                |
| Max. input MPPT<br>current (A)                      | 15/30   | 15/30                    | 15/30                    | 15/30                  |
| Max. input short<br>circuit current per<br>MPPT (A) | 22.5/45   | 22.5/45                  | 22.5/45                  | 22.5/45                |
| Maximum inverter<br>backfeed current to<br>array    | 0A  |                          |                          |                        |
| Output(AC)  |   |                          |                          |                        |
| Rated power (VA)                                    | 8000  | 10000                    | 10000                    | 12000                  |
| Max. AC power<br>(VA)                               | 8800  | 10000                    | 11000                    | 13200                  |
| Rated output<br>current (A)                         | 11.6  | 14.5                     | 14.5                     | 17.4                   |
| Max. output<br>current(A)                           | 13.3  | 15.2                     | 16.7                     | 20                     |
| Nominal grid<br>voltage                             | 3/N/PE, 230V/400Vac                               |                          |                          |                        |
| Grid voltage range                                  | 310Vac-480Vac (According to local standard)       |                          |                          |                        |
| Nominal frequency                                   | 50Hz  |                          |                          |                        |
| Grid frequency<br>range                             | 45Hz-55Hz/54Hz-66Hz (According to local standard) |                          |                          |                        |

|                                       |  |        |        |        |
|---------------------------------------|--|--------|--------|--------|
| Active power adjustable range         | 0~100%                                     |        |        |        |
| THDi                                  | <3%  |        |        |        |
| Power factor                          | 1 default (adjustable+/-0.8)               |        |        |        |
| Current (inrush)                      | 23.9A /20ms                                |        |        |        |
| Maximum output fault current          | 66A ,2μs                                   |        |        |        |
| Maximum output overcurrent protection | 20.0A                                      |        |        |        |
| Performance                           |  |        |        |        |
| Max efficiency                        | 98.50%                                     | 98.50% | 98.50% | 98.50% |
| European weighted efficiency          | 98.00%                                     | 98.00% | 98.00% | 98.00% |
| Self-consumption at night             | <1W  |        |        |        |
| MPPT efficiency                       | >99.9%                                     |        |        |        |
| Protection                            |  |        |        |        |
| DC reverse polarity protection        | Yes  |        |        |        |
| Anti-islanding protection             | Yes  |        |        |        |
| Leakage current protection            | Yes  |        |        |        |
| Ground fault monitoring               | Yes  |        |        |        |
| PV-array string fault monitoring      | Yes  |        |        |        |
| Anti reverse power function           | Yes  |        |        |        |
| DC switch                             | Yes  |        |        |        |
| AFCI protection                       | Optional                                   |        |        |        |
| Input/ output SPD                     | PV: type II standard, AC: type II standard |        |        |        |
| Protective class                      | Class I                                    |        |        |        |
| Overvoltage category                  | PV: OVC II, AC mains: OVC III              |        |        |        |
| Detection methods of isolated islands | Reactive Power Disturbance                 |        |        |        |
| Communication                         |  |        |        |        |

|                                   |  |       |       |       |
|-----------------------------------|--|-------|-------|-------|
| Communication                     | RS485/USB/ Bluetooth, Optional: WiFi /GPRS   |       |       |       |
| General Data                      |  |       |       |       |
| Ambient temperature range         | -30℃~+60℃  |       |       |       |
| Topology                          | Transformerless  |       |       |       |
| Degree of protection              | IP65   |       |       |       |
| Allowable relative humidity range | 0~100%   |       |       |       |
| Max. operating altitude           | 2000m  |       |       |       |
| Noise                             | ≤40dB  | ≤40dB | ≤40dB | ≤40dB |
| Weight                            | 17kg   | 18kg  | 18kg  | 18kg  |
| Cooling                           | Fan  |       |       |       |
| Dimension                         | 430*385*182mm  |       |       |       |
| Display                           | LCD&Bluetooth+APP  |       |       |       |
| Standard warranty                 | 10 years   |       |       |       |
| Standard                          |  |       |       |       |
| EMC                               | EN61000-6-1, EN61000-6-2, EN61000-6-3, EN61000-6-4   |       |       |       |
| Safety standard                   | IEC62109-1/2, IEC62116, IEC61727, IEC61683, IEC60068(1,2,14,30)  |       |       |       |
| Grid standard                     | AS/NZS 4777, VDE V 0124-100, V 0126-1-1, VDE-AR-N 4105, CEI 0-21/CEI 0-16, UNE 206 007-1, EN50549, G98/G99, EN50530, NB/T32004 |       |       |       |

Note: the product may be upgraded in the future. The above parameters are for reference only and are subject to change. Please refer to the real product.

## 9. Quality Assurance

SOFARSOLAR \*Factory's Warranty Terms and Conditions for Australia

Applicable products

These \*Factory's Warranty Terms and Conditions ("Terms and Conditions") only applies to the following products, which are distributed and installed in Australia.

| Product                   | Standard warranty period (months) |
|---------------------------|-----------------------------------|
| Inverter                  |                                   |
| GRID-TIED (3.3~12KTLX-G3) | 120                               |
| Accessories               |                                   |
| CT Clamp                  | 24                                |
| smart Meter               | 24                                |
| WIFI dongle               | 24                                |

\*This factory warranty is a promise from SOFARSOLAR to its end users on the applicable products listed above.

Definitions

In these Terms and Conditions:

- a) "ACL" means Schedule 2 to the Competition and Consumer Act 2010 (Cth);
- b) "Claim" means any judgment, claim, demand, action, suit or proceeding for damages, debt, restitution, equitable compensation, account, injunctive relief, specific performance or any other remedy, whether by original claim, cross claim or otherwise whether arising at common law, in equity, under statute or otherwise wherever arising, whether known or unknown at the time of these Terms and Conditions, whether presently in contemplation of the parties or not;
- c) "Consequential Loss" means loss or damage, whether direct or indirect, in the nature of, among other things, loss of profits, loss of revenue, loss of



production, liabilities in respect of third parties (whether contractual or not), loss of anticipated savings or business, pure economic loss, loss of opportunity and any form of consequential, special, indirect, punitive or exemplary loss or damages, whether or not a party was advised of the possibility of such loss or damage;

d) “End User” means a person or entity whose order for the purchase of the Product is accepted by SOFARSOLAR;

e) “Loss” means, in relation to any person, any damage, loss, cost, expense or liability incurred by the person or arising from any Claim, action, proceedings or demand made against the person, however arising and whether present or future, fixed or ascertained, actual or contingent and includes Consequential loss;

f) “Product” means any applicable product or products distributed and installed by SOFARSOLAR to the End User as set out in the Table of these Terms and Conditions;

g) “Warranty Period” means the applicable warranty period of the relevant Product as stipulated in the Table of these Terms and Conditions.

#### Warranty Conditions

Our goods come with guarantees that cannot be excluded under the ACL. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure. Subject to any statutory rights which cannot be excluded (including the ACL) and the terms of any warranty stipulated in these Terms and Conditions, the End User acknowledges that: prior to purchasing the Product, the End User conducted a thorough examination of the Product;

b) SOFARSOLAR made no warranty, condition, description, or representation in relation to the Product outside those contained in these Terms and Conditions;

c) all warranties, conditions, guarantees, and terms in relation to the state,

quality or fitness of the Product and of every other kind whether expressed or implied by use, statute or otherwise are excluded.

To the fullest extent that SOFARSOLAR is able to limit the remedies available under these Terms and Conditions, SOFARSOLAR expressly limits its liability for any breach of a condition or warranty implied by virtue of any applicable legislation (including the ACL) to the following remedies in the event SOFARSOLAR decides a Product to be faulty or otherwise defective during the Warranty Period (or otherwise):

- a) The repair of the Product by SOFARSOLAR whether on-site or off-site;
- b) The replacement of the Product;
- c) The payment of the costs of having the Product repaired.

The payment of the costs of replacing the Product or acquiring equivalent goods. If the Product needs to be replaced, the balance of the Factor's Warranty Period will be applied and transferred to the replacement Product and will continue until its expiry. In this event, the End User will not receive any new warranty card or be entitled to a further Warranty Period, and the replacement Product(s) will be registered by SOFARSOLAR.

Unless otherwise agreed in writing by the parties, the Factory warranty exclusively covers the cost of one (1) freight to the End User, labour and material necessary to regain a faultless functioning Product. The Factory warranty does not cover, without limitation, Consequential Loss, repair reimbursement costs, transport costs, travel costs, accommodation cost of SOFARSOLAR personnel as well as any costs of associated third party staff and personnel. Express delivery costs will not be covered.

In the event SOFARSOLAR, in its sole discretion, decides that any faulty or otherwise defective Product will be repaired on-site or otherwise replaced, in some service areas or business cases, to encourage the End User using the installer's facilities to receive a faultless and functioning product, SOFARSOLAR may, in its sole discretion, offer a rebate to the End User or local installer/electrician to cover the on-site service labour under the following conditions:

The rebate will be eligible ONLY to the party who has carried out on-site service for the purported faulty or otherwise defective Product;

The purported faulty or otherwise defective Product has been returned in the original replacement product packaging to SOFARSOLAR and deemed to have workmanship or material defects upon testing and inspection by SOFARSOLAR. If the purported faulty or otherwise defective Product is deemed free of faults and defects that would qualify a replacement under these Terms and Conditions, then SOFARSOLAR is entitled to charge a retail price of the Product(s), shipping and packaging and any associated labour cost in replacing the purported faulty or otherwise defective Product;

SOFARSOLAR must be contacted prior to the site visit for authorisation. If the site is not located in a metropolitan area in Australia or if the installer is unable to be on-site, the End User must engage their own electrician to carry out and complete the on-site service;

The service rebate must be claimed strictly within two (2) months of the date upon which the on-site service is authorised by SOFARSOLAR.

SOFARSOLAR retains the right to arrange the warranty service for the End User and to use third parties for performing any warranty services. SOFARSOLAR retains full title and ownership of the supplied replacement Product(s) until the purported faulty or otherwise defective Product has been received in accordance with these terms and conditions.

The End User may contact the dealer (SOFARSOLAR authorised dealer or distributor) or installer if the Product is faulty or otherwise defective.

All other purported costs including, but not limited to, compensation from any direct or indirect Loss arising from the faulty or otherwise defective Product or other facilities of the PV system, or loss of electrical power generated during the product downtime are NOT covered by the SOFARSOLAR limited warranty.

Scope of the Warranty

The warranty stipulated in these Terms and Conditions will not apply if SOFARSOLAR, in its sole discretion, decides that any one (1) of the following occurs:

The End user is in default under the General Terms and Conditions of other agreement governing the purchase of the Product, or

Any damage or defect to the Product is caused any one (1) or more of the following situations (the Dealers or Distributors are responsible and authorized by SOFARSOLAR for the following investigation):

Disassembly, attempted repair or modifications performed by any person not authorised by SOFARSOLAR in writing, or serial number or seals have been removed. Product modifications, design changes or part replacements without prior written approval of SOFARSOLAR;

The End user or installer has failed, refused or otherwise neglected to comply with the applicable safety regulations (IE, VDE standards or equivalent) governing the proper use of the Product in force from time to time;

The Product has been improperly stored and damaged by the dealer, distributor or the End User;

The fault or otherwise defect is damage sustained during transportation (including painting scratch caused by movement inside packaging during shipping). A Claim for such transport damage should be made directly to the shipping company/insurance company as soon as the container/package is unloaded and such damage is identified;

The Product has been used and installed by an unauthorised or unlicensed installer who fails, refuses, or otherwise neglects to strictly follow any applicable user manual, installation guide and maintenance regulations supplied with the Product, including not ensuring sufficient ventilation for the Product as described in SOFARSOLAR installation guide;

Defects, faults, cosmetics or rendered non-functional damage caused by unforeseen circumstances, or force majeure event including, but not limited to, any vandalism, violent or stormy weather, lightning, flooding, power fluctuation, overvoltage, grid power surge, pests, fire damage, wind damage, or exposure to

erosion, sea coasts/saltwater or other aggressive atmospheres or environmental conditions;

Use of the Product in combination with any unauthorised products, equipment or materials as per the user manual, installation guide and maintenance regulations supplied with the Product;

Combining the Product with any lead acid battery pack or any other lithium battery pack that is not listed on any SOFARSOLAR's battery compatibility list from time to time.

#### Limitation of Liability

a) This limited warranty supersedes and otherwise replaces any different SOFARSOLAR warranties and liabilities, whether oral, in writing, (non-obligatory) statutory, contractual, in tort or otherwise, consisting of, without quandary, and where permitted by using relevant law, any implied conditions, warranties or different phrases as regards exemplary quality or fitness for purpose. However, this limited warranty shall neither exclude nor limit any of your legal (statutory) rights provided under the relevant national laws and regulations.

b) Subject to clauses 4(c) and (d):

i. all warranties, descriptions, representations, guarantees or conditions, whether express or implied by law, trade, custom or otherwise, and all specific conditions, even though such conditions may be known to SOFARSOLAR, are, to the fullest extent, expressly excluded;

ii. SOFARSOLAR is not liable for any delay or Loss arising from the supply of or failure to supply the Product or comply with an order of the End User whether due to shortfall, defect, incorrect delivery or otherwise for any reason whatsoever including breach of contract (including fundamental breach), negligence, breach of duty as bailee, or the wilful act or default of SOFARSOLAR.

c) These Terms and Conditions shall not exclude or limit the application of any provisions of any statute including any implied condition or warranty the exclusion of which would contravene any statute (including the ACL) or cause any part of this clause 4 to be illegal, invalid, void or unenforceable.

d) If the exclusion of liability in clause 4(b) is reduced, void or not available, SOFARSOLAR's liability for any Claims arising out of these Terms and Conditions, including liability for breach of these Terms and Conditions, in negligence or in tort or for any other common law or statutory action, shall:

i. be limited to the extent the Loss the subject of the Claim was caused directly by SOFARSOLAR; and

ii. in all events, exclude Loss relating to any delay in supply of the Product and for any Consequential Loss.

e) SOFARSOLAR guarantees the performance of the Product under the normal working conditions within the standard warranty term and provide limited technical support if applicable. However, SOFARSOLAR shall assume no liability for system malfunctions and any incurred loss or damages whatsoever.

Please refer to SOFARSOLAR Energy Storage Warranty Terms and Conditions for further information on SOFARSOLAR Energy Storage products.

#### Procedure for Claiming a Warranty

In the case of a faulty or otherwise defective Product please report that Product within the agreed warranty period, with a detailed error description to SOFARSOLAR's service hotline for registering and send the claim to SOFARSOLAR service department by fax/email or through SOFARSOLAR Warranty Claim Website at <https://service.sofarsolar.com/warranty/search> to process the warranty claim. The End User may also contact the dealer (SOFARSOLAR authorised dealer or distributor) or installer if the Product is defective or faulty.

To make a claim under the warranty, the End User must provide the following information and documentation of the faulty or otherwise defective Product:

Product Model and serial number

A copy of the valid purchasing invoice

Fault descriptions and error IDs (where applicable)

End user and/or claimant details

Detailed information about the entire system (module, PV system diagram, installation date, etc.)

Documentation of previous claims/exchanges (if applicable)

The warranty may not be guaranteed if the above information is not provided.

Extension of the Warranty Period

For SOFARSOLAR inverters, the End User may apply for a Warranty Period extension within 24 months for grid-tied inverter <50kW and 12 months for grid-tied  $\geq 50$  kW and energy storage inverter(hybrid) inverters from the date of production from SOFARSOLAR by providing the serial number and copy of the warranty card of the Product. SOFARSOLAR may reject any application received which does not meet the date requirement. An extended Warranty Period can be purchased to 10, 15, or 20 years. Please refer to the Warranty Extension Order Form for more information.

Once the purchase of the Warranty Period extension has been processed, SOFARSOLAR will send a Warranty Period extension certificate to the End User confirming the extended Warranty Period.

Any faults or defects that occur after the expiry of the Warranty Period, or which occur within the Warranty Period but which are listed in the warranty exceptions above, are deemed to be out-of-warranty cases. For all out-of-warranty cases,

SOFARSOLAR, in its sole discretion, may charge fees to the End User including, without limitation:

- a) On-site service fee: cost of travel and time for the technician to deliver on-site service and labour cost for the technician, who is repairing, performing maintenance on, installing (hardware or software) and debugging the faulty product.
- b) Parts/materials fee: cost of replacement parts/materials (including any shipping/admin fee that may apply).
- c) Logistics fee: cost of delivery and any other expenses incurred when defective products are sent from the user to SOFARSOLAR or/and repaired products are sent from SOFARSOLAR to the user.

Latest information about the warranty terms and conditions and local service hotline can be obtained from our website: [www.sofarsolar.com.au](http://www.sofarsolar.com.au)

#### Contact us

You can directly contact our professional after-sales team:

Sofarsolar Ausco Pty Ltd.

Tel: +61 401 734 463 / 408 500 386

Shenzhen Sofarsolar Co., Ltd.





---

Product Name: PV Grid-Connected Inverter

Company Name: Shenzhen SOFARSOLAR Co., Ltd.

ADD: 401, Building 4, AnTongDa Industrial Park, District 68, XingDong Community,  
XinAn Street, BaoAn District, Shenzhen, Guangdong, P.R. China

Email: [service@sofarsolar.com](mailto:service@sofarsolar.com)

Tel: 0510-6690 2300

Web: [www.sofarsolar.com](http://www.sofarsolar.com)